



Digital Timer

INSTRUCTIONS

407DT20HM

Before Use: Carefully remove plastic strip from battery compartment. This is included to preserve battery life. Remove film from LCD display.

Cleaning and Care: Hand wash only. Do not immerse in water or put in the dishwasher.

Toggle the on/off switch on the back of the timer to power on.



Count down:

1. Press HOUR and MIN to set desired time. Press and hold each button for fast advance.
2. Press START/STOP to start the count down.
3. Press START/STOP to pause and resume the count down.
4. When timer counts down to 0, press RESET to turn off the alarm, or START/STOP to turn off the alarm and activate the count up.
5. Press RESET or HOUR and MIN simultaneously to clear the time.

Note: Set desired time in hours and minutes up to 19 hours and 59 minutes. The last hour counts down in minutes and seconds.

Count up:

1. Press START/STOP to start the count up.
2. Press START/STOP to pause and resume the count up.
3. Press RESET or HOUR and MIN simultaneously to clear the time.

Note: The timer will count up to 19 hours, 59 minutes, and 59 seconds. The first hour will count up in minutes and seconds.