



# COUNTERTOP MILK COOLER

---

#236EMC1 • 1 Gallon

04/2024

# INDEX

Safety Information ..... 2  
 Installation ..... 3  
 Operation ..... 4  
 Cleaning..... 5  
 Troubleshooting..... 5



**Note:** Save these instructions for future reference.

# SAFETY INFORMATION

**DANGER – RISK OF FIRE OR EXPLOSION. FLAMMABLE REFRIGERANT USED. TO BE REPAIRED ONLY BY TRAINED SERVICE PERSONNEL. DO NOT PUNCTURE REFRIGERANT TUBING.**

**PELIGRO - RIESGO DE INCENDIO O EXPLOSION. REFRIGERANTE INFLAMABLE UTILIZADO. PARA SER REPARADO SOLAMENTE POR PERSONAL DE SERVICIO CALIFICADO. NO PINCHAR LA TUBERÍA REFRIGERANTE.**

**DANGER – RISQUE DE FEU OU D’EXPLOSION. LE FRIGORIGÈNE EST INFLAMMABLE. CONFIER LES RÉPARATIONS À UN TECHNICIEN SPÉCIALISÉ. NE PAS PERFORER LA TUBULURE CONTENANT LE FRIGORIGÈNE.**

**CAUTION – RISK OF FIRE OR EXPLOSION. FLAMMABLE REFRIGERANT USED. CONSULT REPAIR MANUAL/ OWNER’S GUIDE BEFORE ATTEMPTING TO SERVICE THIS PRODUCT. ALL SAFETY PRECAUTIONS MUST BE FOLLOWED.**

**ATENCIÓN - RIESGO DE INCENDIO O EXPLOSIÓN. REFRIGERANTE INFLAMABLE UTILIZADO. CONSULTE EL MANUAL DE REPARACIÓN / GUÍA DEL PROPIETARIO ANTES DE INTENTAR DAR SERVICIO A ESTE PRODUCTO. DEBEN CUMPLIR CON TODAS LAS PRECAUCIONES DE SEGURIDAD.**

**ATTENTION – RISQUE DE FEU OU D’EXPLOSION. LE FRIGORIGÈNE EST INFLAMMABLE. CONSULTER LE MANUEL DU PROPRIÉTAIRE/GUIDE DE RÉPARATION AVANT DE TENTER UNE RÉPARATION. TOUTES LE MESURES DE SÉCURITÉ DOIVENT ÊTRE RESPECTÉES.**

**CAUTION – RISK OF FIRE OR EXPLOSION DUE TO PUNCTURE OF REFRIGERANT TUBING; FOLLOW HANDLING INSTRUCTIONS CAREFULLY. FLAMMABLE REFRIGERANT USED.**

**ATENCIÓN - RIESGO DE INCENDIO O EXPLOSIÓN DEBIDO A LA PERFORACION DE LA TUBERÍA REFRIGERANTE; SIGA LAS INSTRUCCIONES DE MANIPULACIÓN CON CUIDADO. REFRIGERANTE INFLAMABLE UTILIZADO.**

**ATTENTION – RISQUE DE FEU OU D’EXPLOSION SI LA TUBULURE CONTENANT LE FRIGORIGÈNE EST PERFORÉE; SUIVRE LES INSTRUCTIONS DE MANUTENTION AVEC SOIN. LE FRIGORIGÈNE EST INFLAMMABLE.**

**CAUTION – RISK OF FIRE OR EXPLOSION DUE TO FLAMMABLE REFRIGERANT USED. FOLLOW HANDLING INSTRUCTIONS CAREFULLY IN COMPLIANCE WITH LOCAL GOVERNMENT REGULATIONS.**

**ATENCIÓN – RIESGO DE INCENDIO O EXPLOSIÓN DEBIDO A REFRIGERANTE INFLAMABLE UTILIZADO. SIGA LAS INSTRUCCIONES DE MANIPULACIÓN CON CUIDADO CONFORME A LAS REGLAS DE LA MUNICIPALIDAD.**

**ATTENTION – RISQUE DE FEU OU D’EXPLOSION SI LE FRIGORIGÈNE EST INFLAMMABLE. SUIVRE LES INSTRUCTIONS DE MANUTENTION AVEC SOIN CONFORMÉMENT AUX RÈGLEMENTATION GOUVERNEMENTALE LOCAUX.**

# INSTALLATION

## Before Installation

- After unboxing, the unit must be kept upright for a minimum of 24 hours in its final installation location before being plugged in. Failure to do so may cause damage to the compressor and will void the warranty.
- Make sure the unit has reached the desired temperature before loading the unit with products.
- Make sure all accessories are installed (shelves, shelf clips, etc.) before plugging in the unit.
- DO NOT attempt to remove or repair any component of the unit. Consult an authorized service technician for servicing / repair.
- DO NOT hang on doors.
- Read through this manual in its entirety.

## Cabinet Location Guidelines

- Install the unit on a strong and leveled surface.
  - If the surface is uneven, the unit may be noisy.
  - The unit may malfunction if the surface is uneven.
- Install the unit in an indoor, well-ventilated area.
  - For best performance, maintain 6" of clearance on both sides and the back of the unit at all times.
  - Outdoor use may cause decreased efficiency and damage to the unit.
  - Avoid direct sunlight.
- Avoid installation in a high humidity and / or dusty area.
  - High humidity can cause the unit to rust and may decrease efficiency.
  - Dust collected on the condenser coil may cause unit to malfunction.
  - Malfunction due to high ambient temperatures, humidity, or improperly maintained condenser coil will void the warranty.
- Select a location away from heat and moisture-generating equipment.
  - High ambient temperatures may cause the compressor to malfunction.
  - Malfunction due to high ambient temperatures and humidity will void the warranty.

## Electrical

- Ensure that the required voltage is being supplied at all times.
- The unit should be plugged into a grounded and properly sized electrical outlet with appropriate over-current protection. Please refer to the electrical requirements on the unit's nameplate.
- The unit should have its own dedicated outlet.
- DO NOT use extension cords.
- Ensure the unit is not resting on or against the electrical cord.
- If the unit is not in use for a long period of time, please unplug the unit from the outlet.
- To avoid shock and fire hazards, DO NOT plug in or unplug the unit with wet hands.
- After unplugging the unit, wait at least 10 minutes before plugging it back in. Failure to do so could cause damage to the compressor.

### Installing the Milk Tube

1. Clean the compatible milk tube that comes standard with your Estella Caffé Presto, Presto Deluxe, or Europa machine.
2. Install the milk tube on the side of your Estella Caffé machine.
3. Pop out the plug on the side of the milk cooler closest to your machine.
4. Make sure the path is clear for the tube to pass through without collecting debris.
5. Place (1) open beverage container of your choice in the refrigerator and feed the tube through the hole, dropping it into the beverage container.

## OPERATION

### Loading Product

- DO NOT block the air duct/fan at the back of the unit.
- DO NOT store flammable and explosive gas or liquids inside the unit.
- Refrigerator display units are meant to maintain already cold product temperature, not actively cool products.

### Temperature Controls

- Your new cooler is already factory-set to run at optimum temperatures for food safety and should require no adjustments.
- Refrigerators are set to cycle between a minimum temperature of 33°F and a maximum temperature of 40°F. Adjusting the temperature changes the minimum temperature your unit will run. Your unit will not run constantly at this setting. To change it, follow these instructions:
  1. Hold “SET” for 1 sec. The display will flash the current minimum temperature.
  2. Use the arrow buttons to adjust the desired minimum temperature.
  3. Press “SET” again to save your settings.  
**Note:** Always remember to calculate the differential if you change the minimum temperature setting. The cabinet temperature will fluctuate up to +7°F over your set minimum temperature as the compressor runs and shuts off. Setting the temperature too high will result in unsafe maximum temperatures and possible health code violations.

### Defrost System

- Refrigeration units contain a manual defrost system.
- Refrigerator coils are kept below the freezing point (32°F).
- During compressor down-time, the evaporator fan continues to circulate air through the evaporator coil. This air circulation raises the coil temperature above the freezing point, melting any accumulated frost.
- Run-off water is drained into the evaporator pan and evaporated.

# CLEANING

## Cleaning the Condenser Coil

- For efficient operation, keep the condenser surface free of dust, dirt, and lint.
- We recommend cleaning the condenser coil at least once per month.
- Clean the condenser with a commercial condenser coil cleaner, such as Noble Chemical Tech Line Coil Clean.

## Cleaning the Fan Blades and Motor

- If necessary, clean the fan blades and motor with a soft cloth.
- If it is necessary to wash the fan blades, cover the fan motor to prevent moisture damage.

## Cleaning the Interior of the Unit

- When cleaning the cabinet interior, use a solvent of warm water and mild soap.
- Do not use steel wool, caustic soap, abrasive cleaners, or bleach that may damage the interior finish.
- Wash door gaskets on a regular basis, preferably weekly. Simply remove the door gasket from the frame of the door, soak it in warm water and soap for thirty (30) minutes, then dry with a soft cloth and replace.
- Check door gaskets for proper seal after they are replaced.

# TROUBLESHOOTING

**NOTE:** We strongly recommend that any servicing be performed by an authorized service technician.

ISSUE	POSSIBLE CAUSE	SOLUTION
Compressor not running.	Fuse blown or circuit breaker tripped.	Replace fuse or reset circuit breaker.
	Power cord unplugged.	Plug in power cord.
	Thermostat set too high.	Set thermostat to lower temperature.
	Cabinet in defrost cycle.	Wait for defrost cycle to finish.
Cabinet temperature is too warm.	Thermostat set too high.	Set thermostat to lower temperature.
	Airflow is blocked.	Re-arrange products to allow for proper airflow. Make sure there is at least four inches of clearance from the fan.
	Low refrigerant levels.	Contact a service technician to check refrigerant levels.
	Door is slightly ajar.	Make sure door is completely closed.
Interior light is not working.	Poor switch connection.	Turn off light switch and turn it back on.
	Bulb is not connected.	Make sure the bulb is correctly inserted in the socket.
	Bulb has burned out.	Replace the bulb.
Compressor is not running.	Gasket is not sealing properly.	Clean, repair, or replace the gasket as necessary.