

InSeason™ Seasoning Dispenser


MODEL: INS

87298

1 COUNT

GREEN TRIGGER

0.46 TSP PORTION



Thank You

for purchasing our InSeason Dispenser™—
This handheld, lightweight model is customized to
dispense precise portions of granular seasonings
for consistent taste and texture.

PERFECTLY SEASONED EVERY TIME!

ASSEMBLY


WASH ALL PARTS
PROPERLY BEFORE USE. See page 3.

1 INSERT TRIGGER ASSEMBLY

With unit upside down on countertop, slide spring end of trigger assembly into side slot. Smooth side of trigger should face down.

Portion size is stamped in trigger cavity.

Green trigger sets 0.46 TSP portion size.



2 INSTALL CLOSER PLATE


into unit body.

Hold closer plate by grasp tab.

Slowly push trigger assembly into unit body.

Ensure spring does not pop loose.

Insert closer plate rim tab into largest interior opening of trigger.



3 INSTALL SPREADER

onto unit body, rotating clockwise to tighten.

4 INSTALL PORTION SHAKER ATTACHMENT

Rotate until it snaps onto spreader edge.

For ease of use, rotate dispensing slots on shaker away from trigger.



5 FILL UNIT

Flip unit right-side up and add granular ingredient.

6 INSTALL LID

onto unit body, rotating clockwise to tighten.



IMPORTANT: Refill when product level falls below fill line.

SAFETY



According to food and safety regulations, most foods must be stored and/or served at certain temperatures or they could become hazardous. Check with local food and safety regulators for specific guidelines. Server Products, Inc. cannot be responsible for the serving of potentially hazardous product.

The dispenser is designed for use in high-heat environments, but is not intended for direct contact with heat sources such as griddle surfaces.

IMPORTANT

Clean, rinse, sanitize, and dry parts daily or regularly to comply with local sanitization requirements.




NSF International listed.

DISASSEMBLY

- 1** REMOVE LID
- 2** EMPTY UNIT
Pour out any remaining ingredient.
- 3** REMOVE PORTION SHAKER ATTACHMENT
- 4** REMOVE SPREADER
- 5** REMOVE CLOSER PLATE
Set unit upside down on countertop.
Grasp tab of closer plate while holding trigger in.
Pull closer plate up and out of unit.
Slowly release trigger to home position, to ensure spring does not pop loose.
- 6** REMOVE TRIGGER ASSEMBLY
from side slot of unit.


REMOVE SPRING FROM TRIGGER only if necessary for cleaning.

- Pry off spring with a flathead screwdriver.
- Push straight end of spring out of center groove in circular tab of trigger.



RE-INSTALL SPRING

- Align straight end of spring into center groove in circular tab of trigger.
- Use flathead screwdriver to press down on straight end of spring.
- Snap spring into circular tab of trigger.



CLEANING

- 1** WASH
After disassembly, wash all parts with dishwashing detergent and hot water.
- 2** RINSE
Fully rinse all parts thoroughly with clear water.
- 3** SANITIZE
all parts according to local sanitization requirements. All parts in contact with food must be sanitized.
- 5** AIR DRY
all parts fully before refilling.


YES!

Use dishwashing soap and hot water

- Dishwasher safe
- Do not use abrasive, caustic or ammonia based cleansers.
- Do not use cleansing agents with high concentrations of acid, alkaline or chlorine.
- Do not use metal scrapers or cleaning pads that could scratch surfaces.



INDIVIDUAL PARTS



TROUBLESHOOTING


INCONSISTENT PORTIONS?

Heat and moisture can cause ingredients to settle and become packed in.

- Shake unit to dislodge light clumping.
- Ensure ingredients have not become clogged within the unit—Disassemble and inspect.
- Clean unit and air dry fully before refilling.
- Ensure ingredient level is above fill line.

TRIGGER WON'T PUSH IN?

- Ensure closer plate is properly installed with rim tab in the largest opening of trigger.



SERVER PRODUCTS LIMITED WARRANTY

2 YEAR
WARRANTY

This Server product is backed by a two-year limited warranty against defects in materials and workmanship. See Server-Products.com for details.

GENERAL SERVICE, REPAIR OR RETURNS

Before sending any item to Server Products for service, repair, or return, contact Server Products customer service to request a **Return Authorization Number**. Merchandise must be sent to Server Products with this number. Service is extremely prompt. Typically, units are repaired and ship out within 48 hours of receipt.

Merchandise being returned for credit must be in new and unused condition and not more than 90 days old and will be subject to a 20% restocking charge.

NEED HELP?

Server Products Inc.

3601 Pleasant Hill Road
Richfield, WI 53076 USA

Chat with us!

spsales@server-products.com

262.628.5600 | 800.558.8722

Please be prepared with your **Model, P/N** and **Series** located on the lid or base of the unit.

Example:

| | | |
|-------------------------------|---|------------------------|
| MODEL XXXX P/N ##### |  | SERIES ###X ###X |
|-------------------------------|---|------------------------|