



IDEAL WAREHOUSE
INNOVATIONS INC
Protecting Your People

Ratchet Top Stabilizing Jack Operation Manual

Important notes:

- Only trained and authorized individuals should use this product.
- Use only original Ideal Warehouse Innovations parts to service this product.
- This product works best on solid surfaces.

Before you begin:

- Complete a visual inspection of the Ratchet Top Stabilizing Jack for any obvious maintenance issues.
- Be careful moving around the maintenance area to ensure it is safe to move around the area.
- Use appropriate personal protective equipment such as gloves, safety glasses, safety vest, hearing protection and protective shoes.



Critical safety tip:

It is a dangerously common practice to use a trailer maintenance jack in lieu of a trailer stand. Because a trailer jack can be lowered even if trailer landing gear has failed, the dock worker is at deadly risk from trailer tip over. Jacks should only be used for the maintenance/tire change operations for which they are designed and should never be used in place of a trailer stand.

Warranty Statement


Ideal Warehouse Innovations, Inc. warrants for a period of three hundred and sixty-five (365) days from date of installation, or three hundred and seventy-five (375) days from date of shipment, whichever shall occur first, that all products and service parts shall be free from defects in workmanship and material. If the equipment or any part thereof, is returned, transportation charges pre-paid, within the periods specified above, and if examination by Ideal Warehouse Innovations, Inc. discloses to its satisfaction that the said equipment or part thereof has been defective in workmanship or material, it will deliver to the purchaser, without charge, parts of the first class workmanship and material in exchange for any parts so found to be defective, and Ideal Warehouse Innovations, Inc. is limited to said exchange.

This warranty shall not apply: (1) to maintenance service or adjustment; and (2) to any equipment which shall have been repaired or altered outside of Ideal Warehouse Innovations, Inc. or its authorized service representatives.

These warranties are in lieu of all other warranties, expressed or implied, including, without limitation, warranties of merchantability and fitness for purpose, all other representations to the first user purchaser, and all other obligations or liabilities, including liability or incidental and consequential damages, on the part of Ideal Warehouse Innovations, Inc. No person is authorized to give any other warranties or to assume any other liability on behalf of Ideal Warehouse Innovations, Inc. unless made or assumed in writing by Ideal Warehouse Innovations, Inc.




Installing the Ratchet Top Stabilizing Jack



Step 1:
Position unit under trailer.



Step 2:
Remove ratcheting handle from base.



Step 3:
Insert handle into ratchet mechanism.



Step 4:
Flip lever into groove to engage 'lift' position.




Step 5:
Use handle in counter-clockwise motion to lift to desired height.



Step 6:
Return handle to stored position.

Removing the Ratchet Top Stabilizing Jack

Complete all of the previous steps in reverse order, except:



Step 7:
When finished, flip lever in opposite direction to engage 'down' position.



Step 8:
Use handle in clockwise motion to lower to desired height.

Once removed, store the unit out of the way of dock traffic and complete a visual inspection to ensure there are no obvious maintenance issues.

Recommended Safety Inspection and Maintenance Schedule

Inspect for	Action
Before each use:	
A visual check should be performed before each use.	Look for any bent parts (ie. handles, top pad, wheels), check for any broken welds, and make sure the handle is present.
Every 90 days:	
Inspect for bent, damaged or missing handlebars, fasteners, grips, wheels, labels, etc.	<ol style="list-style-type: none"> 1. Check to ensure all moving parts operate smoothly. 2. Clean labels so instructions are clear and visible. 3. Replace or repair if necessary.

Ratchet Top Stabilizing Jack Parts Listing

Key	Part #	Description	Qty Per Stand
	60-5453	Ratchet Top Stabilizing Jack	1
1	50-9270	Top Support Plate 8"	1
2	50-9272	Main Column Handle Grip	1
3	50-9274	Main Column & Ratchet Assembly	1
4	50-9276	Axle Washer & Cotter Pin	2
5	50-9278	Ratchet-Top Axle	1
6	50-9280	Ratchet-Top 8" Wheel	2
7	50-9282	Ratchet Tube	1
8	50-9284	Ratchet Tube Handle Grip	1

