Indigo™ Models - Menu Navigation Overview

Press to power ON/OFF

Press to access cleaning function

Press to access Main Menu

Press to select menu/sub-menu option

Navigate Menus

Menu Button

ON/OFF Button

Cleaning Button

Timer Initiated

Home Screen

When Alert Present → Alerts

When Message Present → Messages

Clean Function

AuCS Clean Function

Main Menu

Machine Info ✓

Set-up ✓ → *Password Entry (Optional)*

Energy Saver ✓ → *Password Entry (Optional)*

Factory Defaults ✓ → Factory Defaults Exit

Service ✓

EXIT ✓ → **Return to Home Screen**

90/70 Capacity
- -Capacity in 24 hours
- -Exit

Model Number
- -Model Number
- -Exit

Ice Machine Head Serial Number
- -Ice Machine Head Serial Number
- -Exit

Condenser Serial Number
- -Condenser Serial Number
- -Exit

Warranty
- -Machine
- -Evaporator
- -Compressor
- -Exit

Install Date
- -Installation Date
- -Exit

Manufacture Date
- -Manufacture Date
- -Exit

Main Software Version
- -Main Software Version
- -Revision x.xxx
- -Exit

Display Software Version
- -Display Software Version
- -Revision x.xxx
- -Exit

Exit

Language
- -English
- -French
- -Espanol
- -Portuguese
- -Deutsch
- -Italiano
- -Svenska
- -Suomi
- -Exit

Time/Date
- -Month/Day/Year
- -Time of Day
- -Exit
  - -Save Changes? No/Yes

Time Config
- -Month/Day/Year
- -Day/Month/Year
- -12hr
- -24hr
- -Exit

Units
- -Degrees C
- -Degrees F
- -Kilograms
- -Pounds
- -Gallons
- -Liters
- -Exit

Ice Clarity
- -Clarity On
- -Clarity Off
- -Exit

LCD Brightness
- -Checkmarks 1 to 4
- -Exit

Password On
- -Enter Password
- -Exit

Edit Password
- -Edit Password
- -Exit

Clean Minder
- -Reminder On
- -Reminder Off
- -Set Interval
- -Exit

AuCS Run Time
- -AuCS On
- -AuCS Off
- -Set Interval
- -Exit

Air Filter
- -Auto
- -Off
- -Set Interval
- -Exit

Water Filter
- -Filter Type
  - -None
  - -AR-10000
  - -AR-20000
  - -AR-40000
  - -Exit
- -Auto
- -Off
- -Set Interval
  - -.5 Month
  - -1 Month
  - -2 Months
  - -3 Months
  - -4 Months
  - -5 Months
  - -6 Months
  - -Exit
- -Exit

LUMINICE
- -Bulb Minder
  - -Yes
  - -No
  - -Exit

Ice Bin Sensor
- -None
- -Bin
- -Beverage Dispenser
- -Exit

USB Setup
- -USB Stick
  - -Download Firmware
    - Insert Drive
    - Wait For Completion
  - -Download Configuration
    - Insert Drive
    - Wait For Completion
  - -Export All
    - Insert Drive
    - Wait For Completion
  - -Export Setup
    - Insert Drive
    - Wait For Completion
  - -Exit
- -Exit

Exit

Ice Program
- -Time Program
- -Settings
- -Bin Level
- -Settings
- -Ice Usage
- -Settings

Water Miser
- -On
- -Off
- -Exit

Statistics
- -Ice Usage
  - -Day Capacity/Day
  - -Monday xxxx
  - -Tuesday xxxx
  - -Wednesday xxxx
  - -Thursday xxxx
  - -Friday xxxx
  - -Saturday xxxx
  - -Sunday xxxx
  - -Exit
- -Potable Water
  - -Day Quantity/Day
  - -Monday xxxx
  - -Tuesday xxxx
  - -Wednesday xxxx
  - -Thursday xxxx
  - -Friday xxxx
  - -Saturday xxxx
  - -Sunday xxxx
  - -Exit
- -Energy
  - -Day KWH/Day
  - -Monday xxxx
  - -Tuesday xxxx
  - -Wednesday xxxx
  - -Thursday xxxx
  - -Friday xxxx
  - -Saturday xxxx
  - -Sunday xxxx
  - -Exit
- -Exit

Exit

Data History
- -Current Day
  - -Minimum Freeze
  - -Maximum Freeze
  - -Minimum Harvest
  - -Maximum Harvest
  - -Max Delta T3T4
  - -Delta
  - -T3
  - -T4
  - -RunTime
  - -Ice Production
  - -Cycle Count
  - -Potable Water
  - -Clean cycles
  - -Exit
- -Current Day + 1
- -Current Day + 2
- -Current Day + 3
- -Current Day + 4
- -Current Day + 5
- -Life Time
  - -Install Date
  - -Control Board Replacements Date
  - -Control Board Date Of Manufacture
  - -Runtime
  - -Cycle Count
  - -Potable Water
  - -Clean Cycles
  - -Exit

Real Time Data
- -Status On/Off
- -Time & Temp
  - -Status - On or Off
  - -Time
  - -T1 Thermistor Temperature
  - -T2 Thermistor Temperature
  - -T3 Thermistor Temperature
  - -T4 Thermistor Temperature
  - -T3 & T4 Delta Temperature
  - -100 hz
  - -120 hz
  - -Exit
- -Inputs
  - -Status Off/On
  - -Curtain Switch 1
  - -Curtain Switch 2
  - -LPCO Switch
  - -HPCO Switch
  - -Bin Level Low
  - -Bin Level 2 Medium
  - -Bin Level 3 High
  - -Sensing Ice No/Yes
  - -Water Level Low No/Yes
  - -Water Level High No/Yes
  - -Exit
- -Outputs
  - -Status Off/On
  - -Water Pump Off/On
  - -Hot Gas Valve 1 Off/On
  - -Hot Gas Valve 2 Off/On
  - -Air Pump Off/On
  - -Water Valve Off/On
  - -Dump Valve Off/On
  - -Compressor Control Off/On
  - -AuCS Relay Off/On
  - -Iconic Cleaner Off/On
  - -Exit
- -Exit

Diagnostics
- -Control Board
  - -Self Check
  - -Enable Relays
  - -Exit
- -Temperature Sensors
  - -T1 Thermistor Temperature
  - -T2 Thermistor Temperature
  - -T3 Thermistor Temperature
  - -T4 Thermistor Temperature
  - -Exit
- -Inputs
  - -Curtain Switch 1 Closed/Open
  - -Curtain Switch 2 Closed/Open
  - -LPCO Switch Closed/Open
  - -HPCO Switch Closed/Open
  - -Bin Level Low Closed/Open
  - -Bin Level 2 Medium Closed/Open
  - -Bin Level 3 High Closed/Open
  - -Sensing Ice No/Yes
  - -Water Level Low No/Yes
  - -Water Level High No/Yes
  - -Exit

Manual Harvest
- -Harvest Started
- -Exit

Replace Control Board
- -Manual Setup
  - -Board Install Date
  - -Input Model Number
- -USB Setup
  - -Insert Drive, Press Checkmark
    - Wait For Completion
- -Exit

USB Setup
- -USB Stick
  - -Download Firmware
    - Insert Drive Wait For Completion
  - -Download Configuration
    - Insert Drive Wait For Completion
  - -Export All
    - Insert Drive Wait For Completion
  - -Export Setup
    - Insert Drive Wait For Completion
  - -Exit
- -Exit

Event Log
- -View ELog
  - -Event Code - When Alert Present
- -Clear ELog
- -Exit

Exit