Conversion Instructions



Slanted Hot Dog Roller Rear-Mounted Controls

Convert your Slanted Avantco Hot Dog Rollers (177RG1830SLT or 177RG1850SLT) into rear-mounted control models.

Rear-mounted controls are great for boosting impulse sales at concession stands or convenience stores. Rear-mounted controls are perfect for buffets, MTO stations, or self-serve areas. The placement of the controls helps prevent guests from tampering with them or from accidentally changing any settings.

Recommended: Professional electrician recommended for conversion. Improper conversion may result in void of warranty.

- Carefully flip the machine, so that the rollers are on the table or working service. (Fig. 1) Note: Rollers or motor may shift, please be ready to adjust rollers after conversion. Follow step 1B only if chain is visibly loose or rollers are not turning.
 - **1B:** If needed, slightly loosen the (4) motor screws (circled Fig. 2), and then carefully push the motor down, creating tension in the chain. Re-tighten screws.
- 2. Take off the bottom base.
- 3. Remove the plate without controls. (Fig. 3)
- 4. Remove the plate with controls.(Fig. 4)
- Carefully, pull the control panel with controls through the front opening, slowly moving it through the body of the machine – moving it from the front to the back and out the back opening. (Fig. 5)
 - **Reminder:** Zip ties keeping the wires neat may need to be removed for this conversion. Please use new zip ties (or other wire management solution) once conversion is complete to keep wires neat.
- Once you've carefully pulled through the back opening, align the plate, and secure it with the same screws you removed. (Fig. 6)
 Reminder: Ensure you have the control panel the right way up.
- 7. Straighten out the internal wires and use zip ties (or other wire management solution) to ensure wires are neat and tidy. Then secure the blank plate to the front. (Fig. 7)
 Reminder: Visually inspect the wires to ensure no loose wires are near the fan or motor.
- Re-attach the base bottom base and the conversion is complete. (Fig. 7)
 Reminder: Adjust rollers if necessary, as well as wipe clean your machine before use. (Fig. 8)















