

Specifications

SURFACE

Material: Solution-dyed polypropylene

Weight: 52 ounces/yard²

Construction: Needle-punched

Design: Hobnail

BACKING

Material: Performance rubber

Overall Mat Thickness: 3/8 inch (0.375")

STANDARDS & TESTING

- Passes DOC-FFI-70 for the surface flammability for the surface of carpets

Cleaning Instructions

Berber Roll Good mats can be cleaned using the instructions below:

- Vacuum regularly (daily in high-traffic commercial areas; weekly in lower traffic areas)
- Extract or hose off as needed to remove heavy soil/debris
- Hang mat to dry

Always make sure the mat is dry before placing it back in service.

Installation Instructions

Measure

Determine the number of square feet that you will need. Measure the length and width of the area you wish to cover. Multiply the width by the length to get the square footage of the space. For areas that are not rectangular, break the area into smaller rectangles. Multiply the width times the length for each of the smaller rectangles separately, and add up all the results to arrive at the overall square footage.

Prepare

Remove any old floor coverings, debris, and adhesives from the floor. Clean the entire floor surface of any dust, drywall mud, etc. Once the floor has been cleaned, allow it to dry completely. Allow the matting material to sit in the area uninstalled for several hours so it can acclimate to room temperature prior to installation.

Install

Apply your adhesive to the prepared floor according to the adhesive manufacturer's directions. We recommend CA024 multi-purpose solvent-free adhesive for all installations both indoor and outdoor. Never use an adhesive that contains solvents. Similar to laying carpet, roll the matting out over the installation area and carefully trim the excess material around the perimeter using a utility knife.