

Monterey Barstool Assembly Instructions

1. Position the metal stretcher so the shorter bar is at the front of the stool.



2. Position the metal stretcher between the 4 legs. The legs might have to be flexed slightly outward to fit the stretcher into place.



3. Wrench tighten the 4 bolts and washers as shown.

