

Model-Specific Compatibility Notes [4/18/2017]:

TPP-93D-6: Standard. Requires 874642 rivnut tool kit to field install.

TPP-93D-2: Standard. Requires 874642 rivnut tool kit to field install.

TWT-48: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-67D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

QA-60-24MB-L: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-24M-DS: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-67D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-67D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-27D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TPP-93D-4: Requires 874642 rivnut tool kit to field install.

TWT-60D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-12: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-08: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TUC-60G: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-8M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-30MB: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TPP-60D-2: Standard. Requires 874642 rivnut tool kit to field install.

TSSU-48-12M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TWT-72F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-12: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16D-2: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TUC-48G: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TPP-119: Standard. Requires 874642 rivnut tool kit to field install.

TUC-44: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-93D-6: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-44D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

QA-72-30MB: Requires 874642 rivnut tool kit to field install.

TSSU-36-12M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-27-08: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-10: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TUC-60D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-27FG: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-36-08: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TWT-27G: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-27-12M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-93D-6: Option. Requires 874642 rivnut tool kit to install.

TUC-36: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-48G: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-27D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-24M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-24MB-DS: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-48-12D-4: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TUC-48F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-36: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

QA-48-18MB: Requires 874642 rivnut tool kit to field install.

TSSU-48-12M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-27-08F: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TUC-27: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-27: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-72: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-18M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-36F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-48D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-27F-D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-67D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-10: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TUC-27G: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-93: Option. Requires 874642 rivnut tool kit to install.

TWT-27FG: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-15M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TWT-44: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-72F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-36-12M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TWT-67: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-67: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-30M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-60D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TPP-44D-2: Use after ser. No. 2246116. Requires 874642 rivnut tool kit to field install.

TWT-48F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-18D-2: Option. Requires 874642 rivnut tool kit to install.

TUC-27F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60-32: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-27-12M-C: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-48F-D: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16D-4: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16D-4-HC: Requires 874642 rivnut tool kit to field install.

TUC-48D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-21M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-60-32D-2: Option. Requires 874642 rivnut tool kit to install.

TSSU-60-14: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TWT-60F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-30MB-DS: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TPP-67D-4: Use after ser. No. 2246116. Requires 874642 rivnut tool kit to field install.

TSSU-60-16-DS: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TWT-60-32: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-18M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TWT-93: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-72: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-08: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TWT-60G: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-44F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-36F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-24M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TWT-27F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TPP-60: Standard. Requires 874642 rivnut tool kit to field install. ';

TSSU-27-08D-2: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TPP-67: Use after ser. No. 2246116. Requires 874642 rivnut tool kit to field install.

TPP-93: Use after ser. No. 2246116. Requires 874642 rivnut tool kit to field install.

TSSU-72-18: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TPP-67D-2: Use after ser. No. 2246116. Requires 874642 rivnut tool kit to field install.

TPP-44: Use after ser. No. 2246116. Requires 874642 rivnut tool kit to field install.

TSSU-48-15M: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TWT-60-32D-2: Option. Requires 874642 rivnut tool kit to install.

TSSU-27-12M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-27-08-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-36-08-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-8-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-10-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-12-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-08-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-10-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-12-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16-DS-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-27-08D-2-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-12D-4-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16D-4-LP: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-27-12MB-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-27-12MC-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-36-12MB-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-48-12MB-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-48-15MB-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-48-18MB-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-24MB-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-24MB-DS-LP: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-27-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-36-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-27G-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48G-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60G-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-27D-2-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48D-4-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60D-4-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-27LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-36LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-48-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-27D-2-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-48D-4-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60D-4-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-27F-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TPP-119D-8: Standard. Requires 874642 rivnut tool kit to field install.

TUC-67F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-93F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-10: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TWT-93F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60-32F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48F-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-67F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60-32F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-27F-D2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48F-D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-48F-D4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-119: Requires 874642 rivnut tool kit to field install.

TWT-119: Requires 874642 rivnut tool kit to field install.

TSSU-72-30M-B-ST: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-24M-B-ST: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TWT-44F: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-18-ST: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TPP-119D-2: Standard. Requires 874642 rivnut tool kit to field install.

TPP-119D-4: Standard. Requires 874642 rivnut tool kit to field install.

TPP-119D-6: Standard. Requires 874642 rivnut tool kit to field install.

TUC-93D-4: Option. Requires 874642 rivnut tool kit to field install.

TUC-119D-4: Requires 874642 rivnut tool kit to field install.

TUC-119D-6: Requires 874642 rivnut tool kit to field install.

TUC-119D-2: Requires 874642 rivnut tool kit to field install.

TUC-119D-8: Standard. Requires 874642 rivnut tool kit to field install.

TWT-119D-2: Requires 874642 rivnut tool kit to field install.

TWT-119D-4: Requires 874642 rivnut tool kit to field install.

TWT-119D-6: Requires 874642 rivnut tool kit to field install.

TWT-119D-8: Standard. Requires 874642 rivnut tool kit to field install.

TUC-60F-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-44D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-93D-2: Option. Requires 874642 rivnut tool kit to field install.

TWT-93D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-93D-4: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-48D-2-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60D-2-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-48D-2: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60D-2-LP: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-16-DS-ST: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-24M-B-DS-ST: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-30M-B-DS-ST: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-48-12D-2: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TWT-67HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-44HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-44HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-44F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-44F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-67HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-67F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-67F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-93HD: Option. Requires 874642 rivnut tool kit to field install.

TUC-93F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-93HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-93F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60-32HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60-32HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TUC-60-32F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TWT-60-32F-HD: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-48-18MB-D4: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-30MB-ST-D2: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-16-ST: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-18M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-16: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-12: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-08: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-12M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-24M-B-ST: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-15M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-18M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-12M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-15M-B: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-27-12MC-D-2: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-36-15MB: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-72-12D-4: Option. Requires 874642 rivnut tool kit to field install.

TSSU-72-18D-4: Option. Requires 874642 rivnut tool kit to field install.

TSSU-48-18MB-D2: Option. Use when 11 3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TSSU-60-08D-2: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TSSU-72-16-ST: Optional for standard cutting board. Requires 874642 rivnut tool kit to install.

TUC-27-HC: Requires 874642 rivnut tool kit to field install.

TUC-27G-HC: Requires 874642 rivnut tool kit to field install.

TUC-48-HC: Requires 874642 rivnut tool kit to field install.

TWT-27-HC: Requires 874642 rivnut tool kit to field install.

TWT-27F-HC: Requires 874642 rivnut tool kit to field install.

TUC-48F-HC: Requires 874642 rivnut tool kit to field install.

TSSU-48-8-HC: OPTIONAL FOR STANDARD CUTTING BOARD. REQUIRES 874642 RIVNUT TOOL KIT TO INSTALL.

TSSU-48-10-HC: Requires 874642 rivnut tool kit to field install.

TSSU-60-16-HC: Requires 874642 rivnut tool kit to field install.

TSSU-60-24M-B-ST-HC: Option. Use when 11-3/4" board used on mega cabinet. Requires 874642 rivnut tool kit to install.

TUC-60-HC: Use with any 1/2" thick cutting board. Requires 874642 rivnut tool kit to install.

TSSU-60-8-HC: Requires 874642 rivnut tool kit to field install.

TSSU-60-12-HC: Requires 874642 rivnut tool kit to field install.