

Model-Specific Compatibility Notes [10.22.14]

TDD-4: Used after 8/30/2010 (pcn #4616).

TDD-4-S: Used after 8/30/2010 (pcn #4616).

TRCB-79: On the base of the cabinet in the corners there are holes with rivnuts for either casters or legs. When converting to legs the center hole must be drilled out to allow the stem to go through. This center hole was used to attach skid to cabinet.

TBB-4: Used after 8/30/2010 (pcn #4616).

TRCB-79-86: On the base of the cabinet in the corners there are holes with rivnuts for either casters or legs. When converting to legs the center hole must be drilled out to allow the stem to go through. This center hole was used to attach skid to cabinet.

TBB-4-S: Used after 8/30/2010 (pcn #4616).

TBB-4G-S: Used after 8/30/2010 (pcn #4616).

TDD-4CT: Used after 8/30/2010 (pcn #4616).

TBB-4G: Used after 8/30/2010 (pcn #4616).

TDD-4CT-S: Used after 8/30/2010 (pcn #4616).

TBB-4PT: Used after 8/30/2010 (pcn #4616).

TBB-4PT-S: Used after 8/30/2010 (pcn #4616).

TBB-4G-PT: Used after 8/30/2010 (pcn #4616).

TDD-4G: Used after 8/30/2010 (pcn #4616).

TRCB-82: On the base of the cabinet in the corners there are holes with rivnuts for either casters or legs. When converting to legs the center hole must be drilled out to allow the stem to go through. This center hole was used to attach skid to cabinet.

TRCB-82-84: On the base of the cabinet in the corners there are holes with rivnuts for either casters or legs. When converting to legs the center hole must be drilled out to allow the stem to go through. This center hole was used to attach skid to cabinet.

TRCB-96: On the base of the cabinet in the corners there are holes with rivnuts for either casters or legs. When converting to legs the center hole must be drilled out to allow the stem to go through. This center hole was used to attach skid to cabinet.

TDD-4CT-G: Used after 8/30/2010 (pcn #4616).

TRCB-82-86: On the base of the cabinet in the corners there are holes with rivnuts for either casters or legs. When converting to legs the center hole must be drilled out to allow the stem to go through. This center hole was used to attach skid to cabinet.

TRCB-72: On the base of the cabinet in the corners there are holes with rivnuts for either casters or legs. When converting to legs the center hole must be drilled out to allow the stem to go through. This center hole was used to attach skid to cabinet.