

Model-Specific Compatibility Notes [07/31/2015]:

TUC-67D-4: Requires 874656 brackets and 874642 rivnut tool to install. Order separately. Allow 2-4 weeks leadtime for delivery.

TUC-67D-2: Requires 874656 brackets and 874642 rivnut tool to install. Order separately. Allow 2-4 weeks leadtime for delivery.

TUC-67: Requires 874656 brackets and 874642 rivnut tool to install. Order separately. Allow 2-4 weeks leadtime for delivery.

TUC-67F: Requires 874656 brackets and 874642 rivnut tool to install. Order separately. Allow 2-4 weeks leadtime for delivery.

TUC-67HD: Requires 874656 brackets and 874642 rivnut tool to install. Order separately. Allow 2-4 weeks leadtime for delivery.

TUC-67F-HD: Requires 874656 brackets and 874642 rivnut tool to install. Order separately. Allow 2-4 weeks leadtime for delivery.