



### 15 Inch Dipwell Recommended Installation Procedure

1. Using the Dipwell as a template, mark the holes on the side of the cabinet. Make sure the right side of the Dipwell is at least 1 inch from the right side of cabinet to allow space for the tube clamp.
2. Drill the three holes with a 7/32 inch drill bit.
3. Use the screws to attach the Dipwell to the cabinet.
4. Make a mark ½ inch to the right side of the Dipwell and at the same level at the holes of the Dipwell and drill a hole with the 7/32 inch drill bit.
5. Slide the clamp over the inlet tube as shown and squeeze the ends together with pliers if necessary.
6. Insert the bottom of the inlet tube through the hole on the right side of the Dipwell (the hole is not shown in the diagram) and loosely screw into the cabinet.
7. Adjust the height of the inlet tube so the end is at least one inch above the rim of the sink as shown.
8. Tighten the clamp screw to hold the inlet tube in place.