



INSTRUCTIONS

1. Using PTFE sealing tape or NSF approved pipe dope, screw the male connector into each end of the barrel valve.
2. Attach the barrel valve to the water inlet tube on one end and the plastic tubing on the other end as shown.
3. Attach the remaining male connector to the water supply and then attach to the other end of the plastic tubing.
4. Assemble tail piece and gasket as shown and attach to drain with coupling nut.
5. Insert overflow tube into the drain hole inside the Dipwell.

NSF APPROVED
PART: D6d

6" Round Deep Drawn Dipwell **NSF**

