Drop Mat Shelving

Assembly Instructions

TOOLS REQUIRED:

Rubber Mallet (not included)

PARTS INCLUDED:

- (A) (4) Shelves
- B (4) Posts
- (C) (16) Pairs of Split Sleeves



Assembly Instructions

- 1. Begin by laying out all the pieces on a flat surface.
- 2. **If assembling mobile unit:** Attach casters to the bottom end of each post by pushing them in.

If assembling stationary unit: Skip this step.

- 3. Clip the split sleeve onto a post at least 6" from the bottom. Repeat at the same height on all four posts.
- 4. Insert each of the posts into the four holes of one of the shelves.
- 5. Place the unit in an upright position and gently tap the shelf down with a rubber mallet to lock it in place.
- 6. Repeat this process for as many shelves as you have.

NOTE: Drop mats can be put through a commercial dishwasher for safe cleaning.



SCAN OR CODE

To view a video of the assembly process









