STAND ALONE WATER CLOSET

INSTALLATION INSTRUCTIONS

FM2893 0123 Supersedes 0320

Installation of Toilet Seat and Cleaning:

It is recommended that toilet seat and cover be installed after all trades are finished.

NOTE: All measurements for roughing-in should be taken from finished wall/floor. It is strongly recommended by the manufacturer that installation is carried out by a licensed plumber.

Cleaning Recommendations

The high quality vitreous china finish on all sanitary ware can be maintained by simply using mild soapy water and wiping over. Sanitary ware should not be cleaned with abrasive materials (e.g. steel wool/ scourers). Do not use any corrosive or abrasive cleaning agents containing acids or scouring agents as this may lead to surface damage.

Bleaches can also discolor seats and hinges and therefore should not be used. If your toilet has metal hinges, they should only be cleaned with a mild liquid domestic cleaner, with soft soapsuds or steel & chrome cleaner.

After cleaning, rinse with clean water and polish with a clean, soft cloth.



