

Beer Drip Tray Surface Mount

Assembly Instructions

TOOLS REQUIRED

- (1) Safety Glasses
- (1) Pencil
- (1) Cut resistant gloves
- (1) Hole Saw or Drill Bit
- (use bit size slightly larger than drain outer dimension but smaller than included washer)
- (1) Power Drill
- (1) Flathead Screwdriver
- (1) Adjustable Wrench

HARDWARE:

- (25-29 mm) Drill bit - Glass Rinser
- (25-38 mm) Drill bit - Drainpipe Hole
- (5 mm) Screws (ensure screws used are not too long to go through the top of the bar)

NOTICES:

- Metal edges may be sharp. Handle with caution.
- It is recommended that this product be installed by a qualified installer.
- Be sure to follow all local plumbing and building codes.
- Inspect beer trays for damage before installation.
- Safety goggles and gloves should be worn during installation to prevent personal injury.

Assembly Instructions

1. Remove all contents from carton. Inspect the beer drip tray for any damage prior to installing. Damaged units should not be installed.
2. Position the tray under your faucet(s) and center the tray. With a pencil, mark the outline of the center drain hole of the tray. Also mark the corners once you are sure the tray is straight or otherwise in the position you want it.
3. Place the end of the drain tube on the outline you drew and confirm the size is correct.
4. With the hole saw or drill bit, drill the drain hole through the counter and allow the drain tube to slip through once the hole is drilled.
5. Position the tray according to your markers and screw the locknut onto the drain tube. Tighten the locknut up against the interior surface.
6. Be careful not to screw too tightly as you may crack the interior lining as it compresses the insulation layer. Just tight enough to hold the tray in place at your chosen alignment is enough.

