

BULMAN Products, Inc.

1650 McReynolds Avenue, NW
Grand Rapids, Michigan 49504-2091
616/363-4416, 616/363-4417 Fax: 616/363-0380
www.bulmanproducts.com

ASSEMBLY INSTRUCTIONS FOR WALL RACKS. (T293-__ 4-HIGH, T292-__ 3-HIGH)

**CAUTION: UPRIGHTS MUST BE ATTACHED
TO STUDS, CEMENT, CONCRETE, ETC.
NOT RECOMMENDED FOR USE ON DRYWALL.**

1. POSITION TOP PAPER CUTTER ON UPRIGHTS WITH TEAR OFF BAR FACING UPWARDS.
2. BOLT TOP CUTTER IN 2ND AND 6TH OVAL SLOTS OF UPRIGHTS USING ROUND HEAD BOLTS, LOCK WASHERS, FLAT WASHERS AND HEX NUTS IN SEQUENCE OUTLINED ABOVE.
3. BOLT REMAINING CUTTERS AS IN STEP 2 LEAVING THREE OVAL SLOTS BETWEEN EACH CUTTER MOUNTED.
4. NOTE THAT ROUND HOLES ON END OF EACH UPRIGHT ARE USED TO BOLT COMPLETE ASSEMBLED UNIT TO WALL OR OTHER VERTICAL SURFACE. MOUNTING HARDWARE IS NOT INCLUDED.

