

NEW AGE INDUSTRIAL CORP., INC.

SPECIALIST IN ALUMINUM EXTRUSION & FABRICATION

P.O. BOX 384, EAST HWY. 36
NORTON, KS 67654

TELEPHONE (913) 877-5121
OUT OF STATE WATTS 800-255-0104

WALL SHELF INSTALLATION INSTRUCTIONS

DRILL DESIRED NUMBER OF HOLES IN $1\frac{1}{2}$ "X $1\frac{1}{2}$ " REAR ANGLE TO ALIGN WITH WALL STUDS. ATTACH WALL SHELF TO WALL WITH SCREWS OR BOLTS LARGE ENOUGH TO SUPPORT DESIRED LOAD. A SUPPORT ROD IS REQUIRED ON ALL WALL SHELVES 24" OR MORE IN DEPTH AND OR 66" OR MORE IN LENGTH. RODS (7/16" DIA.) SHOULD BE SECURELY FASTENED TO CEILING OF SECURE OVERHEAD STRUCTURE AND ATTACHED TO WALL SHELVING BY DRILLING A $\frac{1}{2}$ " HOLE IN THE FRONT TUBING LATERAL. IF ONE SUPPORT ROD IS USED IT SHOULD BE PLACED NEAR THE CENTER OF THE FRONT TUBING LATERAL- TWO RODS SHOULD BE PLACED AT EACH END. USE A WASHER UNDER EACH NUT.