





10 Bushel Plastic Folding Laundry Cart

Use and Care Guide

09/2026



User Safety



WARNING
To prevent personal injury.

Prevent Misuse: Do not sit, stand, shake, lean, jump, or climb on cart.

Storage: This cart is intended for commercial cleaning and maintenance use. When not in use, store indoors. Do not store the unit in areas that may block emergency exits or public pathways.

Note: Do not store or throw away items that contain liquid in the cart. This unit is intended for use with dry items only.

Weight Capacity: The unit's total weight capacity is 130 lb. Do not exceed the listed weight capacity.

Assembly

The laundry cart is pre-assembled. Unfold to use. Canvas bag wraps around the top frame and is secured by clasping hooks on side of bag.

Cleaning and Maintenance

Daily Cleaning: Remove loose debris and wipe down with a damp cloth or mild soap solution to prevent buildup.

Assembly Inspection: Regularly inspect parts and ensure structural integrity.

Washing Bag: Hand washing is recommended.

Avoid Machine Drying: Do not machine dry the bag. Air-dry only.

Avoid Ironing: Do not iron the bag.

Inspect Wheels: Do not use the cart if the wheels are damaged or worn.