

VOLLRATH®




HOT, COLD, FROZEN MODULAR DROP-IN

QUICK START USER'S GUIDE

POWERING THE UNIT ON/OFF

1. POWER ON

- Press the Power icon.
- The display screen will light up and show the last used settings for each well.
Default setting: All wells are **OFF**.



2. POWER OFF

- Press the **Power icon** again to turn off the unit. The display will darken, and the last-used settings for each well will be remembered.




SETTING UP WELLS

Each well (identified by a number icon) can be set to one of four modes: **OFF**, **HOT**, **COLD**, or **FROZEN**.

SELECTING A MODE FOR A WELL

1. ACTIVATE A WELL


- Press the **number icon** for the desired well (e.g., Well 1, Well 2). This will activate the well and display its current mode setting.



SELECTING A MODE FOR A WELL (CONTINUED)

2. SCROLL THROUGH MODES


- Press the **number icon** repeatedly to scroll through modes: **OFF**, **HOT**, **COLD**, **FROZEN**.
- Stop at your desired mode (e.g., HOT, COLD). The display will flash for 3 seconds, then go solid, confirming the mode selection.



ADJUSTING TEMPERATURE IN HOT MODE


1. SET HOT MODE FOR A WELL

- Select a well and "scroll to **HOT** mode. Once **HOT** is selected, the display will flash to allow for further adjustments. Rotate the control knob to increase or decrease the heat level.



2. ADJUST HEAT LEVEL


- Push "the control knob"** to activate temperature adjustment.
- Push "the control knob"** furthermore to scroll through wells in Hot mode
- While the display flashes, **rotate the control knob** to increase or decrease the heat level.



SETTING A WELL TO COLD OR FROZEN MODE


1. COLD MODE

- Select a well by pressing its **number icon**.
- Scroll to **COLD** mode. The display will flash for 3 seconds, then go solid to confirm the mode.



2. FROZEN MODE

- Select a well and scroll until **FROZEN** mode appears.
- Wait for the display to stop flashing after 3 seconds, which confirms the mode.
- In frozen mode, ensures food remains frozen and maintains optimal temperature.



ADDITIONAL TIPS

Digital Readouts: Numeric temperature displays are active only in **HOT** mode. The numbers will remain blank in **OFF**, **COLD**, and **FROZEN** modes.