



Funnel Cake & Donut Fryers



#177FBF1824LP

#177FBF2424LP

#177FBF2624LP

#177FBF1824NG

#177FBF2424NG

#177FBF2624NG

Warning:

Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury, or death. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment. If installing the funnel cake and donut fryer with propane (LP) gas, a commercially approved regulator **MUST** be installed on the floor fryer in addition to the tank regulator. Units installed without an external appliance regulator will cause damage to parts and will void the warranty.

For Your Safety:


Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.

Note:

Please read and keep these instructions. Indoor use only.

177FBF1824LP / 177FBF1824NG / 177FBF2424LP 177FBF2424NG / 177FBF2624LP / 177FBF2624NG

Parts Diagram



177FBF1824LP / 177FBF1824NG

Parts List

Key	Description	Item Number	Quantity
1	Housing Assembly	—	1
2	Front Panel	—	1
3	Left-Door Assembly	—	1
4	Temperature Dial Knob	177101103628	1
5	Thermostat Bracket	—	1
6	Thermostat	177202200728	1
7	Hi-Limit Thermostat	177202200737	1
8	Magnet	—	2
9	Drain Extension	177202006273	1
10	Adjustable Legs	177200900019	4
11	Right-Door Assembly	—	1
12A	Pilot Light, Natural Gas	177201302028	1
12B	Pilot Light, Liquid Propane	177201302019	1
13	Thermopile	177201700237	1
14	Pilot Bracket	177026017029	1
15	Pilot Tubing	177201900719	1
16	Pressure Tester	—	1
17	Orifice Extension Base	177202006237	3
18	Manifold Pipe	177201802646	1
19	Union Joint	—	1
20	Elbow Connector	—	2
21	Pressure Tester	—	1
22A	Orifice, Natural Gas #39	177201500573	3
22B	Orifice, Liquid Propane #52	177201500582	3
23A	Natural Gas Valve	177200500773	1
23B	Liquid Propane Valve	177200500782	1
24	Manifold Bracket	—	1
25	Gas Pipe	—	1
26	Burner	177201301400	3
27	Drain Valve	177200500019	1
28	Tank Assembly	—	1
29	Basket Support Screen	17701107755L	1
30A	Donut Screen	17701107764L	1
30B	Donut Screen With Handle	177DNTSCRN18	1
30C	Handle For Donut Screen	17700703028L	2

177FBF1824LP / 177FBF1824NG

Parts List

Key	Description	Item Number	Quantity
31	Plastic Handle	177200700664	1
32	Handle Assembly	177026080014	1
33	Donut Screen Press	17701107773L	1
34	Chimney Outside Board	—	1
35	Inside Chimney Assembly	—	1
36	Cover	177026083008	1
37	Cover Support	1771107782L	1
38	Back Hinge	177026080011	1
39	Front Hinge	17726080012	1
40	Left-Door Hinge	17726080016	1
41	Right-Door Hinge	17726080020	1

177FBF2424LP / 177FBF2424NG

Parts List

Key	Description	Item Number	Quantity
1	Housing Assembly	—	1
2	Front Panel	—	1
3	Left-Door Assembly	—	1
4	Temperature Dial Knob	177101103628	1
5	Thermostat Bracket	—	1
6	Thermostat	177202200728	1
7	Hi-Limit Thermostat	177202200737	1
8	Magnet	—	2
9	Drain Extension	177202006273	1
10	Adjustable Legs	177200900019	4
11	Right-Door Assembly	—	1
12A	Pilot Light, Natural Gas	177201302028	1
12B	Pilot Light, Liquid Propane	177201302019	1
13	Thermopile	177201700237	1
14	Pilot Bracket	177026017029	1
15	Pilot Tubing	177201900719	1
16	Pressure Tester	—	1
17	Orifice Extension Base	177202006237	4
18	Manifold Pipe	17701807991L	1
19	Union Joint	—	1
20	Elbow Connector	—	2
21	Pressure Tester	—	1
22A	Orifice, Natural Gas #39	177201500573	4
22B	Orifice, Liquid Propane #52	177201500582	4
23A	Natural Gas Valve	177200500773	1
23B	Liquid Propane Valve	177200500782	1
24	Manifold Bracket	—	1
25	Gas Pipe	—	1
26	Burner	177201301400	4
27	Drain Valve	177200500019	1
28	Tank Assembly	—	1
29	Basket Support Screen	17701107728L	1
30A	Donut Screen	17701107737L	1
30B	Donut Screen With Handle	177DNTSCRN24	1
30C	Handle For Donut Screen	17700703028L	2

177FBF2424LP / 177FBF2424NG

Parts List

Key	Description	Item Number	Quantity
31	Plastic Handle	177200700664	1
32	Handle Assembly	177026080014	1
33	Donut Screen Press	17701107719L	1
34	Chimney Outside Board	—	1
35	Inside Chimney Assembly	—	1
36	Cover	177026080010	1
37	Cover Support	1771107746L	1
38	Back Hinge	177026080011	1
39	Front Hinge	17726080012	1
40	Left-Door Hinge	17726080016	1
41	Right-Door Hinge	17726080020	1

177FBF2624LP / 177FBF2624NG

Parts List

Key	Description	Item Number	Quantity
1	Housing Assembly	—	1
2	Front Panel	—	1
3	Left-Door Assembly	—	1
4	Temperature Dial Knob	177101103628	1
5	Thermostat Bracket	—	1
6	Thermostat	177202200728	1
7	Hi-Limit Thermostat	177202200737	1
8	Magnet	—	2
9	Drain Extension	177202006273	1
10	Adjustable Legs	177200900019	4
11	Right-Door Assembly	—	1
12A	Pilot Light, Natural Gas	177201302028	1
12B	Pilot Light, Liquid Propane	177201302019	1
13	Thermopile	177201700237	1
14	Pilot Bracket	177026017029	1
15	Pilot Tubing	177201900719	1
16	Pressure Tester	—	1
17	Orifice Extension Base	177202006237	4
18	Manifold Pipe	—	1
19	Union Joint	—	1
20	Elbow Connector	—	2
21	Pressure Tester	—	1
22A	Orifice, Natural Gas #39	177201500573	4
22B	Orifice, Liquid Propane #52	177201500582	4
23A	Natural Gas Valve	177200500773	1
23B	Liquid Propane Valve	177200500782	1
24	Manifold Bracket	—	1
25	Gas Pipe	—	1
26	Burner	177201301400	4
27	Drain Valve	177200500019	1
28	Tank Assembly	—	1
29	Basket Support Screen	1771108491L	1
30A	Donut Screen	1771108500L	1
30B	Donut Screen With Handle	177DNTSCRN26	1
30C	Handle For Donut Screen	17700703028L	2

177FBF2624LP / 177FBF2624NG

Parts List

Key	Description	Item Number	Quantity
31	Plastic Handle	177200700664	1
32	Handle Assembly	177026080014	1
33	Donut Screen Press	1771108519L	1
34	Chimney Outside Board	—	1
35	Inside Chimney Assembly	—	1
36	Cover	177026080010	1
37	Cover Support	1771107746L	1
38	Back Hinge	177026080011	1
39	Front Hinge	17726080012	1
40	Left-Door Hinge	17726080016	1
41	Right-Door Hinge	17726080020	1