



Floor Fryers

Models:

#177FF40N #177FF40L #177FF50N
#177FF50L #177FF100N #177FF100L



Warning:

Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury, or death. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment. If installing the fryer with propane (LP) gas, a commercially approved regulator **MUST** be installed on the fryer in addition to the tank regulator. Units installed without an external appliance regulator will cause damage to parts and will void the warranty.


For Your Safety:

Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.

Note:

Please read instructions thoroughly. Indoor use only.

Floor Fryer Diagram



Key	Description	Part Number	QTY		
			177FF40	177FF50	177FF100
1	Housing	—	1	1	1
2	Fryer Pot Assembly	—	1	1	1
3	Chimney Assembly	—	1	1	1
4A	Chimney Cover for FF40 And FF50	177026061004	1	1	—
4B	Chimney Cover for FF100	177026065004	—	—	1
5A	Door for FF40 and FF50	177026061002	1	1	—
5B	Door for FF100	177026065002	—	—	1
6	Door Hinge	17726037002	1	1	1
7	Bottom Front Panel	—	1	1	1
8	Top Front Panel	—	1	1	1
9	Thermostat Bracket	—	1	1	1
10	Gas Pipe Mounting Bracket	—	1	1	1
11	Sensor Clamp	—	1	1	1
12	Pilot Bracket Connecting Plate	—	1	1	1
13	Adjustable Leg	177200900019	4	4	4
14	Door Magnet	—	1	1	1
15	Drain Valve	177200500019	1	1	1
16	Drain Extension	177202006273	1	1	1
17A	Pilot - Natural Gas	177201302028	1	1	1
17B	Pilot - Liquid Propane	177201302019	1	1	1
18	Safety Thermopile	177201700237	1	1	1
19	Pilot Tube	177201900719	1	1	1
20	High Limit Thermostat	177202200737	1	1	1
21	Thermostat	177202200728	1	1	1
22	Thermostat Knob	177101103628	1	1	1
23	Burner	177201301400	3	4	5
24	Gas Distribution Pipe Assembly	—	1	1	1
25	Manifold Adapter Assembly	—	1	1	1
26A	Combination Valve - Natural Gas	177400042	1	1	1
26B	Combination Valve - Liquid Propane	177400146	1	1	1
27	Straight Joint	—	1	1	1
28	Elbow	—	1	1	1
29	Manifold	—	1	1	1
30	Manifold Elbow	—	1	1	1
31	Manifold Bracket	—	2	2	2
32A	Crumb Screen for FF40	177400037	1	—	—
32B	Crumb Screen for FF50	17701102246	—	1	—
32C	Crumb Screen for FF100	177400056	—	—	1
33	Fryer Basket	—	2	2	2
34A	Orifice #39 - Natural Gas	177201500573	3	4	5
34B	Orifice #52 - Liquid Propane	177201500582	3	4	5