


3 Bulb Food Warmers



1. Place Bottom Lamp Frame (B) on a stable, flat surface.
2. Insert Top Lamp Frame (A) into Bottom Lamp Frame (B) and secure with Screws (C).
3. Screw Shatterproof Bulbs (D) into sockets. (Bulbs included in box)
4. Plug power cord into appropriate socket and switch unit on to check the bulbs.
5. The appliance is now ready for use.



Item: 177W63

12/2020