




UPPER & SIDE HOUSING WARMERS

(A)






'A' & 'B' MODELS ONLY

120V & 120/240V MODELS ONLY

BASE WARMERS

(B)



'A' & 'B' MODELS ONLY

120V & 120/240V MODELS ONLY

WARMER ASSEMBLIES

ITEM	PART NO.	QTY.	DESCRIPTION
A	03652.0000	1	Warmer Assembly 120V, Top & Side Warmers (Includes items 1, & 3 - 6)
	11440.0009	1	Warmer Assembly 220V, Top & Side Warmers (Includes items 1, 3, 5, & 6)
	11440.0011	1	Warmer Assembly 200V, Top & Side Warmers (Includes items 1, 3, 5, & 6)
	01303.0000	3	Screw, Pan Head - SST #4-40 x .5"
	00916.0000	3	Fastener, J-Type #4-40
	1	01227.0000	1 Warmer Element 120V Top & Side Warmers
	01951.0000	1	Warmer Element 220V Top & Side Warmers ("A" Models)
	01951.0001	1	Warmer Element 200V Top & Side Warmers ("B" Models)
B	11440.0005	1	Warmer Assembly 120V, Base Warmers (Includes items 2-7) (Single CW)
	11440.0008	1	Warmer Assembly 220V, Base Warmers (Includes items 2, 3, 5, & 6)
	11440.0010	1	Warmer Assembly 200V, Base Warmers (Includes items 2, 3, 5, & 6)
	01303.0000	3	Screw, Pan Head - SST #4-40 x .5"
	00916.0000	3	Fastener, J-Type #4-40
	2	11442.0000	1 Warmer Element 120V Base Warmers (Single CW)
	11438.0000	1	Warmer Element 220V Base Warmers ("A" Models)
	11438.0001	1	Warmer Element 200V Base Warmers ("B" Models)
3	03656.0000	1	Warmer Dish, Blk 45 Hole
4	13042.0001	1	Spacer, (120V Models Only)
5	05212.0000	1	Plate, Element Retaining
6	00970.0000	2	Nut, Keps #8-32
7	04828.0001 *	2	Tube, Silicone .25" Dia x 1.875" LG. (Order Item 8)
The Following Items Are Not Illustrated			
8	04828.1001	-	Tube, Silicone .25" Dia. x 24" LG (Use as required)
9	24785.0002	1	Galley Kit, "C" Series, 3 Warmers



All warmers listed above are rated @ 100 watts

* Indicates the part number listed is for reference only.