



## BASE - TRUNK - HOOD - COVERS & PANELS

ITEM	PART NO.	QTY.	DESCRIPTION
1	39884.1001	1	Cover Assy, Top BLK (Includes item 2 & 3)
	01315.0005	6	Screw, Truss Head BLK #8 - 32 x .38"
2	37881.0000	2	Decal, "No Serviceable Parts"
3	25151.0000	4	Shield, Insulator
4	39972.0000	1	Schematic, 3 Phase/1 Phase (120/208 & 120/240V models)
	39972.0001	1	Schematic, 3 Phase/1 Phase (230/400V models)
	39972.0002	1	Schematic, 3 Phase/1 Phase (200V models)
5	39530.1001	1	Hood SST (Includes item 6)
	02308.0000	26	Screw, Pan Head #8 - 32 x .375"
6	39544.0000	1	Switch, Membrane
7	39514.1000	1	Panel W/Decals, Trunk Rear (Includes items 8 & 9)
8	00986.0000	1	Decal, Warning - Electrical
9	00656.0001	1	Decal, Comply to Plumbing Code
10	39516.1000	2	Panel W/Decal, Trunk Side (Includes item 11) (1 less used on 230/400V models)
	39516.1001	1	Panel W/Decal, Trunk Right Side (Includes item 11) (230/400V models)
11	39803.0000	1	Decal, Main Power Switch
12	40886.1000	1	Panel, Access EMI Filter (230/400V models only) (Includes items 2 and 21)
	41096.0000	4	Screw, Pin in Torx Head #8 - 32 x .375"
13	39518.1000	1	Panel W/Decals, Trunk SST (Includes items 14 & 15) (120/208V models)
	39518.1001	1	Panel W/Decals, Trunk SST (Includes items 14 & 15) (120/240V models)
	39518.1002	1	Panel W/Decals, Trunk SST (Includes items 14 & 15) (230/400V models)
	01315.0000	6	Screw, Truss Head #8 - 32 x .375"
14	00658.0000	1	Decal, Caution - Decanter/Funnel
15	29710.0015	1	Decal, Optional Field Wiring (120/208V models)
	29710.0019	1	Decal, Optional Field Wiring (120/240V models)
	29710.0020	1	Decal, Optional Field Wiring (230/400V models)
16	39521.1000	1	Panel W/Decal, Trunk SST (Includes item 2)
	01315.0000	2	Screw, Truss Head #8 - 32 x .375"
17	39520.0000	1	Bracket, Server Stop
	01315.0000	4	Screw, Truss Head #8 - 32 x .375"
18	39512.0002*	1	Base Plate
	02308.0000	19	Screw, Pan Head #8 - 32 x .375"
19	40041.0000	4	Leg, Nickel Plated
20	40042.0000	4	Pad, Anti Skid
21	12559.0003	1	Decal, "Warning Hazardous Voltage"