

## DRAIN ACCESSORIES

1. To fill sinks with water, place the white removable drain plug over top of the sink drain, pushing down slightly to seal tightly.
2. To drain water, remove drain plug.
3. To strain water while draining, place green insert strainer down inside the drain hole.



## DRAIN HOSES

1. To attach hose, simply screw onto drain on under side of table.
2. Adjust length of hose as needed by pulling on accordion part of tubing to desired length.
3. Point hose away from camp or into a bucket to drain.



## REMOVABLE FAUCET

1. Faucet attaches to standard water hoses. Use on/off valve to start and stop water flow.

