



# **EduTouch Instruction Manual**



---

**Model # EDTC**



## EduTouch— Sit and Stand Cart

Dear Valued Customer,

Thank you for your purchase. Although extreme care goes into manufacturing and packaging of this product, mistakes are possible. If you encounter any missing parts or difficulty in assembly, etc. please call our toll free customer service line at 1-800-261-4112 for courteous and immediate resolution to your problem.

Sincerely,  
OKLAHOMA SOUND


# EduTouch - Sit and Stand Cart

**Part**

**Description**

**Quantity**

**B**



**Main reading surface**

**1**


**C**



**Adjustable Pole**

**1**

**D**



**Main Base**

**1**

| Part | Description                                                                                           | Quantity |
|------|-------------------------------------------------------------------------------------------------------|----------|
| F    |  Casters Non-Locking | 2        |
| G    |  Casters Locking     | 2        |
| H    |  Allan Bolt—1/2"     | 4        |
| K    |  Main Column Bolts | 2        |

### **Required Tools for Assembly**

1) Crescent Wrench




2) Allan Wrench




### **Step Number One**

Lay down part B (main reading surface) on a clean surface.




### **Step Number Two**

Take part C (adjustable pole ) and align the four holes to the four holes on the main bracket. Install it using four bolts (part H) .



### Step Number Three

Take part D (main base) and assemble it to part C (adjustable pole) using two Column bolts (part K). Using a wrench, fully tighten bolts.



### Step Number Four

Assemble four casters ; Two locking in the front and non-locking in the back. Use a wrench to complete this step.

