

Item No. 554LPG30WG, 554LPG30WGKIT, 554LPG36WG, 554LPG36WGKIT, 554LPG48WG,
554LPG48WGKIT, 554LPG60WGKIT, 554LPG72WGKIT

08.2023

**BACKYARD
PRO®**

WIND GUARD FOR LP GRILL

Quick Start Guide



- + Retain this manual for future reference.
- + Unit must be kept clear of combustibles at all times.

TABLE OF CONTENTS

Introduction & Assembly	2
Operation & Cleaning	3

INTRODUCTION

Congratulations on your purchase of a Backyard Pro Wind Guard or Wind Guard LP Grill Kit. Please read the following warnings, assembly instructions, and operation instructions to get the best and safest use out of your purchase.



SAFETY WARNINGS



Backyard Pro LP Outdoor Grills are designed, built, and sold for commercial use and should be operated by trained personnel only. Clearly post all **DANGERS, CAUTIONS, WARNINGS**, and **OPERATING INSTRUCTIONS** near each unit to insure proper operation and to reduce the chance of personal injury and/or equipment damage.

DANGER: DO NOT use oven for indoor cooking or heating. Toxic fumes can accumulate and cause asphyxiation. Do not use in or on boats or recreational vehicles.

WARNING: Improper installation, adjustment, alteration, service, or maintenance could cause injury or property damage. Read the installation, operation, and maintenance instructions thoroughly. Failure to follow these instructions could result in fire or explosion that could cause property damage, personal injury, or death.

WARNING: NOTE: The use and installation of this product must conform to local codes. In absence of local codes, use the National Fuel Gas Code, ANSI Z223.1/NFPA54, Natural Gas and Propane Installation Code, CSA B149.1, or Propane Storage and Handling Code, B149.2. Please note these units are only certified for the above noted gas applications.

WARNING: It is important that the roll dome is completely secured to your grill at all times during operation.

WARNING: Do not touch metal parts of the grill or roll dome until it has cooled for 45-60 minutes to avoid burns, unless you are wearing protective gear (BBQ mittens, pot holders, etc.).

ASSEMBLY

To assemble your Backyard Pro Wind Guard, simply fit the three sides between the grill grates and side of the grill and you are ready to start grilling. If you already own a Backyard Pro LP grill and want to add a wind guard, check the below chart to find the correct item for your grill.

GRILL	DESCRIPTION	WIND GUARD	QTY
554LPG30	30" LP GRILL	554LPG30WG	1
554LPG36	36" LP GRILL	554LPG36WG	1
554LPG48	48" LP GRILL	554LPG48WG	1
554LPG60	60" LP GRILL	554LPG30WG	2
554LPG72	72" LP GRILL	554LPG36WG	2

STARTUP

Once you have installed the wind guard, follow the instructions for lighting your grill found in your grill manual.

CLEANING AND MAINTENANCE

HOT WARNING - To prevent injury, please allow the grill and wind guard to cool down for 45-60 minutes prior to removing the wind guard from the grill.

CLEANING INSTRUCTIONS

1. Clean wind guard when necessary. It is recommended to wipe down with warm, soapy water weekly.
2. See below for grill cleaning instructions.

CLEANING YOUR GRILL

1. Do not clean any part of your barbecue grill in a self-cleaning oven.
2. Do not use oven cleaners, abrasive kitchen cleaners, cleaners that contain citrus products, or mineral spirits.
3. Do not use any type of steel bristled brush.
4. Clean your grill regularly to prohibit grease build-ups and avoid a grease fire or excessive flare-ups.
5. Always allow the grill to cool down prior to cleaning.

STAINLESS STEEL

Clean with multipurpose, low abrasive, non-phosphorous metal or stainless steel polish and a soft cloth. Always polish in the direction of the lines. Do not allow grease and dirt to accumulate. In addition, the following products and naturally occurring substances in the outdoors will damage all stainless steel finishes. Use caution so that they do not come in contact with your gas grill. Immediately wash them off and dry the stainless steel should they ever come in contact with your gas grill. This includes, but is not limited to, pool chemicals (chlorine and bromine), lawn fertilizer, ice melting salts, sea or salt water, bird droppings, and tree sap.

OTHER EXTERIOR SURFACES

Wash with a mild dish soap and warm water. A cloth, soft brush, or plastic cleaning pad can be used. Rinse thoroughly and wipe dry.

NOTE: Rust is not covered under warranty.

NOTE: For further grill cleaning instructions please see your grill user manual

TRANSPORTATION

For transportation, it is recommended to remove the wind guard from the grill to prevent damage.