

72" Thermoplastic Expanded or Perforated Rectangular Picnic Table



ASSEMBLY INSTRUCTIONS

PARTS LIST

A-E Table Top (1)




B-E Seat (2)



OR


A-P Table Top (1)



B-P Seat (2)



C Leg(2)




D V-Link (2)



HARDWARE

A A Head Screws and Nuts
M8 x 30mm (16)
Washers (32)



B B Anchor (4)



C C Concrete Screws
M6 x 30mm (8)



D D Drill Bit
M5 x 80mm (1)



EXPANDED METAL



PERFORATED METAL




72" Thermoplastic Expanded or Perforated Rectangular Picnic Table



ASSEMBLY INSTRUCTIONS


STEP 1

Assemble of the Legs(C) & Table Top(A-E or A-P)




STEP 2

Assemble of the V-Link (D) onto the 2 Legs & Table Top



STEP 3

Assemble of the Legs & Seats (B-E or B-P)



72" Thermoplastic Expanded or Perforated Rectangular Picnic Table

ASSEMBLY INSTRUCTIONS



STEP 4

Mounting Hardware Instruction

1. Using provided drill bit, drill hole into the concrete, block or stone to a depth of 2-1/2"
2. Blow out the dust in the hole
3. Place anchor over tubing
4. Secure screw flush with anchor into drill hole.
5. Repeat on remaining screws.

