

### www.rhinocoffeegear.com

Thank you for purchasing our RHINO POCKET SCALE. With normal care and proper treatment, this scale will provide years of reliable service.

### **General Maintenance and Care**

- 1. Avoid exposure to extreme heat or cold. Also avoid any kind of moisture. Always allow your scale to acclimate to normal room temperature before use.
- 2. Keep your scale in a clean and dry environment. Dust, dirt, moisture, vibration, air currents and proximity to other electronic equipment may have an adverse effect on the accuracy and reliability of the scale.
- 3. Handle the scale with care. Gently apply all items to be weighed on the tray top. Although this scale is designed to be quite durable, avoid rough treatment, as this may permanently damage the internal parts. Always avoid shaking and dropping. This is a precision instrument and should be handled with extreme care.

## **Specification and Function**

- 1. Capacity: 1000g, Accuracy: 0.1g
- 2. Units: g, oz, ozt, dwt, ct, gn
- 3. Key function: ON/OFF, MODE, TARE, CAL
- 4. Display: LCD display with backlight
- 5. Auto off: 180 seconds of inactivity by default. Auto-off time could be set to 60/120/180 seconds or disabled manually.
- 6. Power: 2 x AAA batteries
- 7. Operation Temp: 10 to 30 deg C

### Operation

- 1. Place the scale on a leveled surface & press "ON/OFF" key to turn on the scale or power it off.
- 2. Wait until the LCD display shows zero, then press "MODE" key to choose the weighing
- 3. Place the item to be weighed on the platform and wait until the reading is stable.

## **Tare Function**

- 1. Turn on the scale as described above.
- 2. Place the "tare item" on the platform. Press "Z/T" key and wait until the LCD displays zero.
- 3. Scale can now be used for weighing. Add the "net-weight-item".

#### Calibration

- 1. When the scale is turned off, press ON/OFF key to turn on the scale, until zero is displayed.
- 2. Press "CAL" key and the display shows "CAL". Press "CAL" key again, the required weight flashes on the display. Place the required weight onto the centre of the platform.
- 3. The LCD display reads "PASS" and comes back to the normal weighing mode.

# **Auto-Off setting**

By default, the scale will turn off automatically after 180 seconds of inactivity.

To change the Auto-Off time setting or disable this function, please follow these steps:

- 1. Press ON/OFF to power off the scale.
- 2. Press and hold the MODE key, at the same time press ON/OFF key 4-5 times quickly.
- 3. LCD shows 180. Press MODE key to switch from 0 sec (auto-off disabled) 60 sec 120 sec 180 sec.
- 4. Press ON/OFF to turn the scale off.

If user chooses "0" second in previous step, it means Auto-Off function is disabled. To keep a longer battery life, please turn the scale off by pressing "ON/OFF" key after each use.

## Warning

- 1. "LO": Low voltage. Please replace the batteries.
- 2. "EEEE" or "O-Ld": Overload. Please remove item quickly to protect the scale.