



# Mini Digital Timer

## INSTRUCTIONS

914MDT100M

**Before Use:** Carefully remove plastic strip from battery compartment. This is included to preserve battery life. Remove film from LCD display.

**Cleaning and Care:** Hand wash only. Do not immerse in water or put in the dishwasher.

---



### Count down:

1. Press MIN and SEC to set desired time. Press and hold each button for fast advance.
2. Press START/STOP to start the count down.
3. Press START/STOP to pause and resume the count down.
4. When timer counts down to 0, press START/STOP to turn off the alarm and recall last time setting.
5. Press MIN and SEC simultaneously to clear the time.

**Note:** *Set desired time in minutes and seconds up to 99 minutes and 59 seconds.*

### Count up:

1. Press START/STOP to start the count up.
2. Press START/STOP to pause and resume the count up.
3. Press MIN and SEC simultaneously to clear the time.

**Note:** *The timer will count up to 99 minutes and 59 seconds.*