

Conversion possibilities JS036C + JS036F = JS072 JS036C + JS052F = JS088

HS Code 73269098 Tariff Code: 9403200020 (US) Barcode: 5425023481363 Made in Sweden (EU)

Contents:

1x base 2x crossbar 1x cylinder 1x center pole 4x upright with plateholders (arms) with 8cm (3 1/4inch) spacing. 1x wing-nut

Quantity plates: 4x 9 plates

Weight & Dimensions

1 box, 80x49x23cm, 12kgs/ Assembled: 89x48x48cm

1 box, 19x19x35inch, 26lbs Assembled: 30x22x10inch

Min/max plate size Min: 12cm (4,73inch) Max: 30-32cm (12,60inch)

The Jackstack[®] plate racks are all made up of a welded steel construction with black electrostatic powder coating finish, which is scratch and rust resistant.

Maintenance : regular washing

<u>**Guarantee**</u>: 2 year worldwide on any manufacturing default.

Jackstack International N.V.

Zoutelaan 28 8300 Knokke-Heist, Belgium Phone: +32 50 621020 Fax: +32 50 615757 E-mail: <u>info@jackstack.com</u> <u>www.jackstack.com</u>

JS036C

Quick and easy assembly Adjustable within seconds To take any size of plate

Jackstack International N.V.

The world's fastest & most versatile preparation serving & storage system

Assembly instructions:

- Take the base
- Position one crossbar under the central column
- Tighten the cylinder and lock with allen key
- Fit the cylinder into the hole in the middle of the base
- Fit the second crossbar above the central column and lock with wing-nut
- Fit the four uprights between the two crossbars, arrows pointing upwards

Adjustments:

• The only correct setting is when the plates rest on all four plastic o-rings. For changing to other plate dimensions, unloose the wingnut to the section you want to change, adjust uprights accordingly and tighten down the wing-nut again.

