

# How to install Casters

## Assembly Instructions

### TOOLS REQUIRED

Casters (included)


Broom Stick (not included)

Allen Wrench (not included)


(A)



(B)



(C)



### Assembly Instructions

1. Begin by using an Allen wrench to remove the legs from the tabletop by loosening the screws in the gussets.



2. Push a broom handle all the way through the leg, pushing the bullet feet out of the legs.



3. Take your caster and screw the top clockwise to adjust the width of the rubber stem. Twist the rubber stem clockwise until it fits snug into the leg.



4. Once the casters are inserted in the legs, tighten them by turning them counter clockwise.



5. Reattach the legs to the tabletop. Assembly complete.

