SERVICE DOCUMENT

How to Replace the Grids and Heating Elements on a Carnival King Waffle Iron



To Replace the Grids

ALWAYS UNPLUG EQUIPMENT PRIOR TO SERVICE

- 1. Remove the nut on the top of the iron.
- 2. There is a 5mm Allen head bolt that can now be accessed through the hole. Loosen that bolt.

Now the waffle iron cover can be pulled aside. Or, you can remove the heating element wires to remove the cover completely.

- 3. Remove the 2 screws holding the heating element in place. The grid plate can now be replaced.
- 4. Repeat steps for other side of iron.

To Replace the Heating Elements

ALWAYS UNPLUG EQUIPMENT PRIOR TO SERVICE

- 1. Follow steps 1 through 3 above.
- Replace the elements. Make sure the wiring connections will not touch the covers when the grid is reattached.
- 3. Repeat steps for other side of iron.

