



CLEANING YOUR DIPWELL

Cleaning in place - cabinet or wall mounted Standard Dipwell (D10s1 & D15s1)

1. Your new stainless steel Dipwell must be cleaned DAILY.
2. Use a simple cleaner such as soap and water, **Bon Ami** cleanser or an ammonia based cleaner at the recommended strength on bottle. **DO NOT USE CHLORINE BLEACH BASED CLEANERS OR HYDROCHLORIC / MURIATIC ACID AS THIS WILL RUST AND DAMAGE YOUR DIPWELL AND OTHER THINGS MADE OF STAINLESS STEEL.**
3. Use a new/clean sponge. **DO NOT USE ANYTHING THAT CAN SCRATCH THE STAINLESS STEEL'S SURFACE (STEEL WOOL, METAL BRUSHES or METAL SCRAPERS)** and make it susceptible to rust.
4. Remove the overflow tube and clean it separately with soap, hot water and a brush.
5. Remove the black rubber bumper and with a cloth or sponge, cleaning the length of it in the crevice and allow to dry.
6. Clean the inside of your Dipwell, removing any deposits and food and rinse thoroughly.
7. Dry with a soft cloth or towel and allow to dry overnight – oxygen in the air helps maintain the passivity film of the stainless steel which protects it from rust. **DO NOT LEAVE WATER SITTING ON THE SURFACE OF THE METAL** – hard water left sitting on the surface will leave water spots and can break down the layer of protection as well as leave food deposits.
8. Replace the cleaned bumper and overflow tube and you are good to go!

Cleaning clip-mounted, removable NSF Dipwell (D10d & D20d) or (D6d) round counter model

1. Your new stainless steel Dipwell must be cleaned DAILY.
2. **For the D10d:** If you choose to put into dishwasher, unscrew plumbing fitting on the bottom of Dipwell sink.
3. Lift Dipwell up **VERTICALLY. DO NOT PULL HORIZONTALLY** or you may bend or break the clips.
4. Remove the overflow tube **(does not apply to the Eco Scoop Shower which does not use an overflow tube)**, take off the bumper and place Dipwell and overflow tube in the dishwasher.
5. Clean rubber bumper with a cloth or sponge, cleaning the length of it in the crevice and allow to dry.
6. When Dipwell is clean and dry, replace the cleaned bumper onto Dipwell then re-mount the Dipwell by fitting the clips located on the back into the slots of the back plate.
7. Re-attach bottom plumbing fitting and hand turn to a tight fit. Replace the overflow tube and you are good to go.
8. **If you decide not to use a dishwasher, follow above instructions for cleaning in place.**
9. **For the D6d** round counter model: Lift Dipwell out of the counter and place in dishwasher along with overflow tube or clean in place (above).

USING YOUR DIPWELL

- Store ice cream scoops and spades in the running water of the Dipwell.
- Wash your utensils in the Dipwell between flavors and tap the scoop on the rubber bumper to knock off excess water - this will keep ice crystals from forming in the ice cream and return the water that is on the utensil into the Dipwell and not the floor.
- When your Dipwell is not in use, do not allow dirty water to sit in it.
- DO NOT plug the overflow tube. This unit works by dilution and washing away of waste with the running water.
- REMEMBER: bacteria begins to grow in as little as 10 minutes on milk products and ice cream. Keep your Dipwell clean and water running when in use!

US FEDERAL HEALTH CODE

Your Dipwell fulfills the US Federal Health Code published by the US Department of Health and Human Services:

3-304.12 In-Use Utensils, Between-Use Storage:

During pauses in FOOD preparation or dispensing, FOOD preparation and dispensing UTENSILS shall be stored: Subsection (D); In running water of sufficient velocity to flush particulates to the drain, if used with moist FOOD such as ice cream or mashed potatoes.