Model-Specific Compatibility Notes [08/07/2014]:

GDM-23F-2: Use before 6/27/02 production date or approx. serial no. 1-3324430.

GDM-35SL-F: Used on cabinets built before 7/1/2002.

T-12FG: Use before 9/18/02 production date.

GDM-23F: Use before 6/27/02 production date or approx. serial no. 1-3324430.

GDM-49DT: Used on cabinets built before 7/1/2002.

GDM-10F: Use before 9/18/02 production date.

T-23FG: Used before 7/1/2002. Replaces Ranco control previously used.

TS-23FG: Used before 7/1/2002. Replaces Ranco control previously used.

TR-56F: Used on cabinets built before 10/25/2003.

TM-56F: Used on cabinets built before 7/1/2002.

T-72FG: Used before 7/2/02 production date.

GDM-23F-RF: Use before 6/27/02 production date or approx. serial no. 1-3324430.

T-72F: Used to replace 800312 cutler hammer control previously used.

GDM-26F-2: Use before 6/28/02 production date or approx. serial no. 1-3324430.

TS-35F: Used on cabinets built before 7/1/2002.

T-49FG: Used before 7/2/02 production date.

TR-56F-4: Used on cabinets built before 10/25/2003.

T-19F: Used to replace 800312 cutler hammer control previously used.

T-23F-2: Used before 7/1/2002. Replaces Ranco control previously used.

T-49DT-G: Used on cabinets built before 7/1/2002.

TS-72F: Used to replace 800312 cutler hammer control previously used.

TS-23F: Used before 7/1/2002. Replaces Ranco control previously used.

T-23F: Used before 7/1/2002. Replaces Ranco control previously used.

TM-24FG: Used on cabinets built before 7/1/2002.

TM-52FG: Used on cabinets built before 7/1/2002.

GDM-19F: Used before 7/1/02 production date.

TR2FRI-2S: N/A

TS-23F-2: Used before 7/1/2002. Replaces Ranco control previously used.

T-49DT-4: Used on cabinets built before 7/1/2002.

GDM-43F: Used on cabinets built before 7/1/2002.

TM-52F: Used on cabinets built before 7/1/2002.

TM-24F-2: Used on cabinets built before 7/1/2002.

TM-24F: Used on cabinets built before 7/1/2002.

GDM-26F: Use before 6/28/02 production date or approx. serial no. 1-3324430.

T-49DT: Used on cabinets built before 7/1/2002.

T-35F: Used on cabinets built before 7/1/2002.

GDM-12F: Use before 9/18/02 production date.

GDM-35F: Used before 7/1/02 production date and may require new relay. .

TM-52F-4: Used on cabinets built before 7/1/2002.

GDM-49F: Use before 7/2/02 production date and may require a new relay.

GDM-72F: Used before 7/2/02 production date and may require a new relay.

T-49DT-1-G-1: Used on cabinets built before 7/1/2002.

T-23FG-2: Used before 7/1/2002. Replaces Ranco control previously used.

GDM-72F DOLLAR GENERAL: Used before 7/2/02 production date and may require a new relay.

TA2FRI-2S: N/A

TG2FRI-2S: N/A