

915173 Compatibility Notes - 12/02/2016	
Model	Notes
TSSU-60-12	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16D-2	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-10	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16D-4	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-14	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16-DS	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-08	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-08-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-10-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-12-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16-DS-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16D-4-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16-DS-ST	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16-ST	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.

TSSU-60-08D-2	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-72-16-ST	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-08-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-12-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TSSU-60-16D-4-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.