

**Model-Specific Compatibility Notes [11/17/2014]:**

**GEM-49:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**GEM-49FC:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**TSD-47G:** Used after ~7/21/2009 (pcn #4131) check work order for correct compressor.

**GDM-47RL:** Used after ~10/23/2008 (pcn #4131) check work order for correct compressor.

**GDM-49W:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**GDM-47:** Used after ~10/23/2008 (pcn #4131) check work order for correct compressor.

**TSD-47:** Used after ~7/21/2009 (pcn #4131) check work order for correct compressor.

**GDM-47FC:** Used after ~10/23/2008 (pcn #4131) check work order for correct compressor.

**GDM-49RL:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**GEM-45:** Used between 7/29/2008 and 6/17/2010 (pcn #4611) check work order for correct compressor.

**GDM-49:** Used before 6/15/2010 (pcn #4599) model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor. Unit after 8/1/13 may be built with the Danfoss compressor, please check work order.

**GEM-47FC:** Used after ~10/23/2008 (pcn #4131) check work order for correct compressor.

**GDM-49W-RF:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**GEM-47:** Used after ~10/23/2008 (pcn #4131) check work order for correct compressor.

**GDM-49FC:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**GDM-49RF:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**GDM-45:** Used between 7/29/2008 and 6/17/2010 (pcn #4611) check work order for correct compressor.

**GDM-49 DOLLAR GENERAL:** Model may be built with either Embraco, Tecumseh, or Danfoss

compressor. Must check work order for correct compressor.

**GEM-49 SUBWAY:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**GDM-49 FAMILY DOLLAR:** Model may be built with either Embraco, Tecumseh, or Danfoss compressor. Must check work order for correct compressor.

**TCGR-48FA:** N/A