Model-Specific Compatibility Notes [12/02/2014]:

- **T-49:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GEM-49:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GEM-37:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **T-72-6:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GDM-49DT:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GEM-69FC:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GDM-35:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **T-72G-6:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GDM-69:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **T-23-2:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GDM-23PT:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **T-23-1-G-1:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GDM-23RL:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GDM-41:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- **GDM-72:** Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.
- GEM-49FC: Programmable digital to change from Celsius to Fahrenheit. For factory installed or

GDM-60: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-23: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-69: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TS-49G: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-35: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-47RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-19: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-35G: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-23G-PT: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-45HL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-23G-2: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-69RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49DT-G: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49G-RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-43: Programmable digital to change from Celsius to Fahrenheit. For factory installed or

GDM-47: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49G-PT: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-72G: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-23RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-37: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-23: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49G: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-49RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49DT-4: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-72: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49-2-G-2: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-45: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-23G-RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-23G: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-33: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-49: Programmable digital to change from Celsius to Fahrenheit. For factory installed or

GDM-72FC: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-37HL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-26: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-47: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-61: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-23FC: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-23: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-72RL: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-72-3-G-3: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49DT: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49G-4: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49-4: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-49PT: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-26: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-49PT: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-45: Programmable digital to change from Celsius to Fahrenheit. For factory installed or

T-49DT-1-G-1: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGU-2: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGU-1: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGU-1F: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGU-3: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGU-3F: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGU-2F: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GEM-61FC: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

GDM-23-2: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

T-23PT: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGW-1: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGW-2: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGW-2F: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGW-3: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGW-3F: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.

TGW-1F: Programmable digital to change from Celsius to Fahrenheit. For factory installed or

T-49-4PT: Programmable digital to change from Celsius to Fahrenheit. For factory installed or replacement of an original factory installation. ft 2157.