

## 831920 Compatibility Notes - 5/17/2018

Model	Notes
G4SM-23	REQUIRES 5 TOTAL PADS
G4SM-23FC	REQUIRES 5 TOTAL PADS
G4SM-23PT	REQUIRES 5 TOTAL PADS
G4SM-23-RGS	REQUIRES 5 TOTAL PADS
G4SM-23RL	REQUIRES 5 TOTAL PADS
G4SM-23RL-SI	REQUIRES 5 TOTAL PADS
GDIM-26	REQUIRES 5 TOTAL PADS
GDIM-26NT	REQUIRES 5 TOTAL PADS
GDIM-49	REQUIRES 5 TOTAL PADS
GDIM-49NT	REQUIRES 5 TOTAL PADS
GDIM-60	REQUIRES 5 TOTAL PADS
GDIM-72NT	REQUIRES 5 TOTAL PADS
GDM-09	REQUIRES 5 TOTAL PADS
GDM-09K	REQUIRES 5 TOTAL PADS
GDM-09PT	REQUIRES 5 TOTAL PADS
GDM-10	REQUIRES 5 TOTAL PADS
GDM-10-52	REQUIRES 5 TOTAL PADS
GDM-10F	REQUIRES 5 TOTAL PADS
GDM-10LE	REQUIRES 5 TOTAL PADS
GDM-10PT	REQUIRES 5 TOTAL PADS
GDM-10PT-LE	REQUIRES 5 TOTAL PADS
GDM-10RF	REQUIRES 5 TOTAL PADS
GDM-10RF-LE	REQUIRES 5 TOTAL PADS
GDM-12	REQUIRES 5 TOTAL PADS
GDM-12F	REQUIRES 5 TOTAL PADS
GDM-12FC	REQUIRES 5 TOTAL PADS
GDM-12LE	REQUIRES 5 TOTAL PADS
GDM-12LE-RF	REQUIRES 5 TOTAL PADS
GDM-12PT	REQUIRES 5 TOTAL PADS
GDM-12PT-LE	REQUIRES 5 TOTAL PADS
GDM-12RF	REQUIRES 5 TOTAL PADS
GDM-14	REQUIRES 5 TOTAL PADS

GDM-14RF	REQUIRES 5 TOTAL PADS
GDM-15	REQUIRES 5 TOTAL PADS
GDM-19	REQUIRES 5 TOTAL PADS
GDM-22	REQUIRES 5 TOTAL PADS
GDM-22F	REQUIRES 5 TOTAL PADS
GDM-23-2	REQUIRES 5 TOTAL PADS
GDM-23F	REQUIRES 5 TOTAL PADS
GDM-23F FAMILY DOLLAR	REQUIRES 5 TOTAL PADS
GDM-23F-2	REQUIRES 5 TOTAL PADS
GDM-23FC	REQUIRES 5 TOTAL PADS
GDM-23FC-RF	REQUIRES 5 TOTAL PADS
GDM-23F-RF	REQUIRES 5 TOTAL PADS
GDM-23HL	REQUIRES 5 TOTAL PADS
GDM-23PT	REQUIRES 5 TOTAL PADS
GDM-23RF	REQUIRES 5 TOTAL PADS
GDM-23RL	REQUIRES 5 TOTAL PADS
GDM-23W	REQUIRES 5 TOTAL PADS
GDM-23W-RF	REQUIRES 5 TOTAL PADS
GDM-26	REQUIRES 5 TOTAL PADS
GDM-26F	REQUIRES 5 TOTAL PADS
GDM-26F FAMILY DOLLAR	REQUIRES 5 TOTAL PADS
GDM-26F-2	REQUIRES 5 TOTAL PADS
GDM-26HL	REQUIRES 5 TOTAL PADS
GDM-26RF	REQUIRES 5 TOTAL PADS
GDM-26W	REQUIRES 5 TOTAL PADS
GDM-26W-RF	REQUIRES 5 TOTAL PADS
GDM-29-SO	REQUIRES 5 TOTAL PADS
GDM-33	REQUIRES 5 TOTAL PADS
GDM-33C	REQUIRES 5 TOTAL PADS
GDM-33CPT	REQUIRES 5 TOTAL PADS
GDM-33CPT-44	REQUIRES 5 TOTAL PADS
GDM-33CPT-48	REQUIRES 5 TOTAL PADS
GDM-33CPT-52	REQUIRES 5 TOTAL PADS
GDM-33CPT-54	REQUIRES 5 TOTAL PADS

GDM-33SL	REQUIRES 5 TOTAL PADS
GDM-33SL-60	REQUIRES 5 TOTAL PADS
GDM-33SL-60LE	REQUIRES 5 TOTAL PADS
GDM-33SSL-54	REQUIRES 5 TOTAL PADS
GDM-33SSL-54 COKE/MCDONALDS	REQUIRES 5 TOTAL PADS
GDM-35	REQUIRES 5 TOTAL PADS
GDM-35F	REQUIRES 5 TOTAL PADS
GDM-35RF	REQUIRES 5 TOTAL PADS
GDM-35SL-60	REQUIRES 5 TOTAL PADS
GDM-35SL-F	REQUIRES 5 TOTAL PADS
GDM-35SL-RF	REQUIRES 5 TOTAL PADS
GDM-35SW-60	REQUIRES 5 TOTAL PADS
GDM-35W-RF	REQUIRES 5 TOTAL PADS
GDM-37	REQUIRES 5 TOTAL PADS
GDM-37HL	REQUIRES 5 TOTAL PADS
GDM-41	REQUIRES 5 TOTAL PADS
GDM-41C	REQUIRES 5 TOTAL PADS
GDM-41C-48	REQUIRES 5 TOTAL PADS
GDM-41CPT	REQUIRES 5 TOTAL PADS
GDM-41CPT-48	REQUIRES 5 TOTAL PADS
GDM-41SL	REQUIRES 5 TOTAL PADS
GDM-41SL-54	REQUIRES 5 TOTAL PADS
GDM-41SL-60	REQUIRES 5 TOTAL PADS
GDM-43	REQUIRES 5 TOTAL PADS
GDM-43F	REQUIRES 5 TOTAL PADS
GDM-45	REQUIRES 5 TOTAL PADS
GDM-45HL	REQUIRES 5 TOTAL PADS
GDM-47	REQUIRES 5 TOTAL PADS
GDM-47FC	REQUIRES 5 TOTAL PADS
GDM-47RL	REQUIRES 5 TOTAL PADS
GDM-49	REQUIRES 5 TOTAL PADS
GDM-49 DOLLAR GENERAL	REQUIRES 5 TOTAL PADS
GDM-49DT	REQUIRES 5 TOTAL PADS
GDM-49F	REQUIRES 5 TOTAL PADS

GDM-49F DOLLAR GENERAL	REQUIRES 5 TOTAL PADS
GDM-49F FAMILY DOLLAR	REQUIRES 5 TOTAL PADS
GDM-49FC	REQUIRES 5 TOTAL PADS
GDM-49PT	REQUIRES 5 TOTAL PADS
GDM-49RF	REQUIRES 5 TOTAL PADS
GDM-49RL	REQUIRES 5 TOTAL PADS
GDM-49W	REQUIRES 5 TOTAL PADS
GDM-49W-RF	REQUIRES 5 TOTAL PADS
GDM-57	REQUIRES 5 TOTAL PADS
GDM-60	REQUIRES 5 TOTAL PADS
GDM-61	REQUIRES 5 TOTAL PADS
GDM-61FC	REQUIRES 5 TOTAL PADS
GDM-69	REQUIRES 5 TOTAL PADS
GDM-69FC	REQUIRES 5 TOTAL PADS
GDM-69HL	REQUIRES 5 TOTAL PADS
GDM-69RL	REQUIRES 5 TOTAL PADS
GDM-72	REQUIRES 5 TOTAL PADS
GDM-72 DOLLAR GENERAL	REQUIRES 5 TOTAL PADS
GDM-72 FAMILY DOLLAR	REQUIRES 5 TOTAL PADS
GDM-72F	REQUIRES 5 TOTAL PADS
GDM-72F DOLLAR GENERAL	REQUIRES 5 TOTAL PADS
GDM-72F FAMILY DOLLAR	REQUIRES 5 TOTAL PADS
GDM-72FC	REQUIRES 5 TOTAL PADS
GDM-72RL	REQUIRES 5 TOTAL PADS
GEM-10	REQUIRES 5 TOTAL PADS
GEM-10FC	REQUIRES 5 TOTAL PADS
GEM-12	REQUIRES 5 TOTAL PADS
GEM-12FC	REQUIRES 5 TOTAL PADS
GEM-19	REQUIRES 5 TOTAL PADS
GEM-23	REQUIRES 5 TOTAL PADS
GEM-23FC	REQUIRES 5 TOTAL PADS
GEM-23RF	REQUIRES 5 TOTAL PADS
GEM-26	REQUIRES 5 TOTAL PADS
GEM-26 SUBWAY	REQUIRES 5 TOTAL PADS

GEM-37	REQUIRES 5 TOTAL PADS
GEM-45	REQUIRES 5 TOTAL PADS
GEM-47	REQUIRES 5 TOTAL PADS
GEM-47FC	REQUIRES 5 TOTAL PADS
GEM-49	REQUIRES 5 TOTAL PADS
GEM-49FC	REQUIRES 5 TOTAL PADS
GEM-61FC	REQUIRES 5 TOTAL PADS
GEM-69	REQUIRES 5 TOTAL PADS
GEM-69FC	REQUIRES 5 TOTAL PADS
GEM-72	REQUIRES 5 TOTAL PADS
GEM-72FC	REQUIRES 5 TOTAL PADS
QA-48-18MB	REQUIRES 5 TOTAL PADS
QA-60-24MB-L	REQUIRES 5 TOTAL PADS
QA-72-30MB	REQUIRES 5 TOTAL PADS
T-12	REQUIRES 5 TOTAL PADS
T-12F	REQUIRES 5 TOTAL PADS
T-12FG	REQUIRES 5 TOTAL PADS
T-12G	REQUIRES 5 TOTAL PADS
T-17F-2	REQUIRES 5 TOTAL PADS
T-19	REQUIRES 5 TOTAL PADS
T-19E	REQUIRES 5 TOTAL PADS
T-19E-FZ	REQUIRES 5 TOTAL PADS
T-19F	REQUIRES 5 TOTAL PADS
T-19FZ	REQUIRES 5 TOTAL PADS
T-19G	REQUIRES 5 TOTAL PADS
T-23	REQUIRES 5 TOTAL PADS
T-23-1-G-1	REQUIRES 5 TOTAL PADS
T-23-2	REQUIRES 5 TOTAL PADS
T-23DT	REQUIRES 5 TOTAL PADS
T-23DT-1-G-1	REQUIRES 5 TOTAL PADS
T-23DT-G	REQUIRES 5 TOTAL PADS
T-23F	REQUIRES 5 TOTAL PADS
T-23F-1-G-1	REQUIRES 5 TOTAL PADS
T-23F-2	REQUIRES 5 TOTAL PADS

T-23FG	REQUIRES 5 TOTAL PADS
T-23FG-2	REQUIRES 5 TOTAL PADS
T-23FZ	REQUIRES 5 TOTAL PADS
T-23G	REQUIRES 5 TOTAL PADS
T-23G-2	REQUIRES 5 TOTAL PADS
T-23G-PT	REQUIRES 5 TOTAL PADS
T-23G-RL	REQUIRES 5 TOTAL PADS
T-23PT	REQUIRES 5 TOTAL PADS
T-23RL	REQUIRES 5 TOTAL PADS
T-24-GC	REQUIRES 5 TOTAL PADS
T-24-GC-S	REQUIRES 5 TOTAL PADS
T-28G-2	REQUIRES 5 TOTAL PADS
T-35	REQUIRES 5 TOTAL PADS
T-35F	REQUIRES 5 TOTAL PADS
T-35FG	REQUIRES 5 TOTAL PADS
T-35FZ	REQUIRES 5 TOTAL PADS
T-35G	REQUIRES 5 TOTAL PADS
T-36-GC	REQUIRES 5 TOTAL PADS
T-36-GC-S	REQUIRES 5 TOTAL PADS
T-49	REQUIRES 5 TOTAL PADS
T-49-2-G-2	REQUIRES 5 TOTAL PADS
T-49-4	REQUIRES 5 TOTAL PADS
T-49-4PT	REQUIRES 5 TOTAL PADS
T-49DT	REQUIRES 5 TOTAL PADS
T-49DT-1-G-1	REQUIRES 5 TOTAL PADS
T-49DT-4	REQUIRES 5 TOTAL PADS
T-49DT-G	REQUIRES 5 TOTAL PADS
T-49F	REQUIRES 5 TOTAL PADS
T-49F-2-G-2	REQUIRES 5 TOTAL PADS
T-49F-4	REQUIRES 5 TOTAL PADS
T-49FG	REQUIRES 5 TOTAL PADS
T-49FZ	REQUIRES 5 TOTAL PADS
T-49G	REQUIRES 5 TOTAL PADS
T-49G-4	REQUIRES 5 TOTAL PADS

T-49G-PT	REQUIRES 5 TOTAL PADS
T-49G-RL	REQUIRES 5 TOTAL PADS
T-49MHC	REQUIRES 5 TOTAL PADS
T-49PT	REQUIRES 5 TOTAL PADS
T-49RL	REQUIRES 5 TOTAL PADS
T-72	REQUIRES 5 TOTAL PADS
T-72-3-G-3	REQUIRES 5 TOTAL PADS
T-72-6	REQUIRES 5 TOTAL PADS
T-72F	REQUIRES 5 TOTAL PADS
T-72F-6	REQUIRES 5 TOTAL PADS
T-72FG	REQUIRES 5 TOTAL PADS
T-72FZ	REQUIRES 5 TOTAL PADS
T-72G	REQUIRES 5 TOTAL PADS
T-72G-6	REQUIRES 5 TOTAL PADS
TA2F-2G	
TA2FPT-2S-2S	USED AFTER 10/30/11 PRODUCTION DATE AND SERIAL # 1-7284923 WICKING KITS NOT USED BEFORE. REQUIRES 5 TOTAL PADS
TA2FRI-2S	USED AFTER 10/30/11 PRODUCTION DATE AND SERIAL # 1-7284923 WICKING KITS NOT USED BEFORE. REQUIRES 5 TOTAL PADS
TA2RRI-2S	
TAC-14GS	REQUIRES 24 TOTAL PADS
TAC-27K	REQUIRES 24 TOTAL PADS
TAC-30	REQUIRES 38 TOTAL PADS BEFORE 11/25/14, USES 26 PADS AFTER 11/24/14 PER PCN 7954
TAC-30GS	REQUIRES 38 TOTAL PADS BEFORE 11/25/14, USES 26 PADS AFTER 11/24/14 PER PCN 7954
TAC-36	REQUIRES 52 TOTAL PADS
TAC-36GS	REQUIRES 52 TOTAL PADS
TAC-48	USED BEFORE 2/8/2006 (PCN #3213) REQUIRES 38 TOTAL PADS
TAC-48GS	USED BEFORE 2/8/2006 (PCN #3213) REQUIRES 38 TOTAL PADS
TAC-72	REQUIRES 52 TOTAL PADS
TAC-72GS	REQUIRES 52 TOTAL PADS
TC-23	REQUIRES 5 TOTAL PADS
TC-23F	REQUIRES 5 TOTAL PADS
TC-23G	REQUIRES 5 TOTAL PADS
TC-49	REQUIRES 5 TOTAL PADS

TC-49G	REQUIRES 5 TOTAL PADS
TC-72	REQUIRES 5 TOTAL PADS
TC-72G	REQUIRES 5 TOTAL PADS
TCGR-77	REQUIRES 5 TOTAL PADS
TCGR-77-CD	REQUIRES 5 TOTAL PADS
TDB-24-48	REQUIRES 5 TOTAL PADS
TDB-24-48-1-G-1	REQUIRES 5 TOTAL PADS
TDB-24-48G	REQUIRES 5 TOTAL PADS
TDB-24-48-GAL-1-G-1	REQUIRES 5 TOTAL PADS
TDBD-72-2	REQUIRES 5 TOTAL PADS
TDBD-72-4	REQUIRES 5 TOTAL PADS
TDBD-96-3	REQUIRES 5 TOTAL PADS
TDBD-96-6	REQUIRES 5 TOTAL PADS
TDD-2	REQUIRES 5 TOTAL PADS
TDD-2CT	REQUIRES 5 TOTAL PADS
TDD-2CT-S	REQUIRES 5 TOTAL PADS
TDD-2-S	REQUIRES 5 TOTAL PADS
TDD-3	REQUIRES 5 TOTAL PADS
TDD-3CT	REQUIRES 5 TOTAL PADS
TDD-3CT-S	REQUIRES 5 TOTAL PADS
TDD-3G	REQUIRES 5 TOTAL PADS
TDD-3-S	REQUIRES 5 TOTAL PADS
TDD-4	REQUIRES 5 TOTAL PADS
TDD-4CT	REQUIRES 5 TOTAL PADS
TDD-4CT-G	REQUIRES 5 TOTAL PADS
TDD-4CT-S	REQUIRES 5 TOTAL PADS
TDD-4G	REQUIRES 5 TOTAL PADS
TDD-4-S	REQUIRES 5 TOTAL PADS
TDG-36-12	REQUIRES 5 TOTAL PADS
TDG-48-18	REQUIRES 5 TOTAL PADS
TDG-50-18	REQUIRES 5 TOTAL PADS
TDG-65-24	REQUIRES 5 TOTAL PADS
TDG-95-38	REQUIRES 5 TOTAL PADS

TG2F-2G	USED AFTER 10/30/11 PRODUCTION DATE AND SERIAL # 1-7284923 WICKING KITS NOT USED BEFORE. REQUIRES 5 TOTAL PADS
TG2FPT-2S-2S	USED AFTER 10/30/11 PRODUCTION DATE AND SERIAL # 1-7284923 WICKING KITS NOT USED BEFORE. REQUIRES 5 TOTAL PADS
TGU-1	REQUIRES 5 TOTAL PADS
TGU-1F	REQUIRES 5 TOTAL PADS
TGU-2	REQUIRES 5 TOTAL PADS
TGU-2F	REQUIRES 5 TOTAL PADS
TGU-3	REQUIRES 5 TOTAL PADS
TGU-3D-2	REQUIRES
TGU-3F	REQUIRES 5 TOTAL PADS
TGW-1	REQUIRES 5 TOTAL PADS
TGW-1F	REQUIRES 5 TOTAL PADS
TGW-2	REQUIRES 5 TOTAL PADS
TGW-2F	REQUIRES 5 TOTAL PADS
TGW-3	REQUIRES 5 TOTAL PADS
TGW-3F	REQUIRES 5 TOTAL PADS
THF-29FL	REQUIRES 5 TOTAL PADS
THF-41FL	REQUIRES 5 TOTAL PADS
THF-51FL	REQUIRES 5 TOTAL PADS
TMC-34	REQUIRES 5 TOTAL PADS
TMC-49	REQUIRES 5 TOTAL PADS
TMC-49-DS	REQUIRES 5 TOTAL PADS
TMC-58	REQUIRES 5 TOTAL PADS
TMC-58-DS	REQUIRES 5 TOTAL PADS
TPP-119	REQUIRES 5 TOTAL PADS
TPP-119D-2	REQUIRES 5 TOTAL PADS
TPP-119D-4	REQUIRES 5 TOTAL PADS
TPP-119D-6	REQUIRES 5 TOTAL PADS
TPP-119D-8	REQUIRES 5 TOTAL PADS
TPP-44	REQUIRES 5 TOTAL PADS
TPP-44D-2	REQUIRES 5 TOTAL PADS
TPP-60	REQUIRES 5 TOTAL PADS
TPP-60D-2	REQUIRES 5 TOTAL PADS

TPP-67	REQUIRES 5 TOTAL PADS
TPP-67D-2	REQUIRES 5 TOTAL PADS
TPP-67D-4	REQUIRES 5 TOTAL PADS
TPP-93	REQUIRES 5 TOTAL PADS
TPP-93D-2	REQUIRES 5 TOTAL PADS
TPP-93D-4	REQUIRES 5 TOTAL PADS
TPP-93D-6	REQUIRES 5 TOTAL PADS
TR2F-2G	USED AFTER 10/30/11 PRODUCTION DATE AND SERIAL # 1-7284923 WICKING KITS NOT USED BEFORE. REQUIRES 5 TOTAL PADS
TR2FPT-2S-2S	USED AFTER 10/30/11 PRODUCTION DATE AND SERIAL # 1-7284923 WICKING KITS NOT USED BEFORE. REQUIRES 5 TOTAL PADS
TR2FRI-2S	
TRCB-110	REQUIRES 5 TOTAL PADS
TRCB-50	REQUIRES 5 TOTAL PADS
TRCB-72	REQUIRES 5 TOTAL PADS
TRCB-79	REQUIRES 5 TOTAL PADS
TRCB-79-86	REQUIRES 5 TOTAL PADS
TRCB-82	REQUIRES 5 TOTAL PADS
TRCB-82-84	REQUIRES 5 TOTAL PADS
TRCB-82-86	REQUIRES 5 TOTAL PADS
TRCB-96	REQUIRES 5 TOTAL PADS
TS-12	REQUIRES 5 TOTAL PADS
TS-12G	REQUIRES 5 TOTAL PADS
TS-19	REQUIRES 5 TOTAL PADS
TS-19FZ	REQUIRES 5 TOTAL PADS
TS-23	REQUIRES 5 TOTAL PADS
TS-23-1-G-1	REQUIRES 5 TOTAL PADS
TS-23-2	REQUIRES 5 TOTAL PADS
TS-23F	REQUIRES 5 TOTAL PADS
TS-23F-2	REQUIRES 5 TOTAL PADS
TS-23FG	REQUIRES 5 TOTAL PADS
TS-23G	REQUIRES 5 TOTAL PADS
TS-23G-2	REQUIRES 5 TOTAL PADS
TS-23G-PT	REQUIRES 5 TOTAL PADS

TS-23G-RL	REQUIRES 5 TOTAL PADS
TS-23PT	REQUIRES 5 TOTAL PADS
TS-28	REQUIRES 5 TOTAL PADS
TS-28-2	REQUIRES 5 TOTAL PADS
TS-28-2-G-2PT	REQUIRES 5 TOTAL PADS
TS-28-2PT	REQUIRES 5 TOTAL PADS
TS-28G-2	REQUIRES 5 TOTAL PADS
TS-28G-2PT	REQUIRES 5 TOTAL PADS
TS-28G-PT	REQUIRES 5 TOTAL PADS
TS-28G-RL	REQUIRES 5 TOTAL PADS
TS-28PT	REQUIRES 5 TOTAL PADS
TS-35	REQUIRES 5 TOTAL PADS
TS-35F	REQUIRES 5 TOTAL PADS
TS-35G	REQUIRES 5 TOTAL PADS
TS-49	REQUIRES 5 TOTAL PADS
TS-49-1-G-3	REQUIRES 5 TOTAL PADS
TS-49-2-G-2	REQUIRES 5 TOTAL PADS
TS-49-4	REQUIRES 5 TOTAL PADS
TS-49DT-G	REQUIRES 5 TOTAL PADS
TS-49F	REQUIRES 5 TOTAL PADS
TS-49F-2-G-2	REQUIRES 5 TOTAL PADS
TS-49F-4	REQUIRES 5 TOTAL PADS
TS-49FG	REQUIRES 5 TOTAL PADS
TS-49G	REQUIRES 5 TOTAL PADS
TS-49G-4	REQUIRES 5 TOTAL PADS
TS-53-4-G-4PT	REQUIRES 5 TOTAL PADS
TS-53-4PT	REQUIRES 5 TOTAL PADS
TS-53G-PT	REQUIRES 5 TOTAL PADS
TS-53G-PT-2G-2S	REQUIRES 5 TOTAL PADS
TS-53G-RL	REQUIRES 5 TOTAL PADS
TS-72	REQUIRES 5 TOTAL PADS
TS-72-3-G-3	REQUIRES 5 TOTAL PADS
TS-72-6	REQUIRES 5 TOTAL PADS
TS-72F	REQUIRES 5 TOTAL PADS

TS-72F-6	REQUIRES 5 TOTAL PADS
TS-72FG	REQUIRES 5 TOTAL PADS
TS-72G	REQUIRES 5 TOTAL PADS
TS-72G-6	REQUIRES 5 TOTAL PADS
TSD-33	REQUIRES 5 TOTAL PADS
TSD-33G	REQUIRES 5 TOTAL PADS
TSD-47	REQUIRES 5 TOTAL PADS
TSD-47G	REQUIRES 5 TOTAL PADS
TSD-69	REQUIRES 5 TOTAL PADS
TSD-69G	REQUIRES 5 TOTAL PADS
TSID-36-2	REQUIRES 24 TOTAL PADS.
TSID-36-4	REQUIRES 24 TOTAL PADS.
TSID-48-2	REQUIRES 5 TOTAL PADS
TSID-48-2-L	REQUIRES 5 TOTAL PADS
TSID-48-4	REQUIRES 5 TOTAL PADS
TSID-48-4-L	REQUIRES 5 TOTAL PADS
TSID-72-2	REQUIRES 5 TOTAL PADS
TSID-72-2-L	REQUIRES 5 TOTAL PADS
TSID-72-3	REQUIRES 5 TOTAL PADS
TSID-72-3-L	REQUIRES 5 TOTAL PADS
TSID-72-4	REQUIRES 5 TOTAL PADS
TSID-72-4-L	REQUIRES 5 TOTAL PADS
TSID-72-6	REQUIRES 5 TOTAL PADS
TSID-72-6-L	REQUIRES 5 TOTAL PADS
TSID-96-3	REQUIRES 5 TOTAL PADS
TSID-96-6	REQUIRES 5 TOTAL PADS
TSSU-27-08	REQUIRES 5 TOTAL PADS
TSSU-27-08D-2	REQUIRES 5 TOTAL PADS
TSSU-27-08D-2-LP	REQUIRES 5 TOTAL PADS
TSSU-27-08-LP	REQUIRES 5 TOTAL PADS
TSSU-27-12M	REQUIRES 5 TOTAL PADS
TSSU-27-12M-B	REQUIRES 5 TOTAL PADS
TSSU-27-12MB-LP	REQUIRES 5 TOTAL PADS
TSSU-27-12M-C	REQUIRES 5 TOTAL PADS

TSSU-27-12MC-D-2	REQUIRES 5 TOTAL PADS
TSSU-27-12MC-LP	REQUIRES 5 TOTAL PADS
TSSU-36-08	REQUIRES 5 TOTAL PADS
TSSU-36-08-LP	REQUIRES 5 TOTAL PADS
TSSU-36-12M	REQUIRES 5 TOTAL PADS
TSSU-36-12M-B	REQUIRES 5 TOTAL PADS
TSSU-36-12MB-LP	REQUIRES 5 TOTAL PADS
TSSU-36-15MB	REQUIRES 5 TOTAL PADS
TSSU-48-08	REQUIRES 5 TOTAL PADS
TSSU-48-10	REQUIRES 5 TOTAL PADS
TSSU-48-10-LP	REQUIRES 5 TOTAL PADS
TSSU-48-12	REQUIRES 5 TOTAL PADS
TSSU-48-12D-2	REQUIRES 5 TOTAL PADS
TSSU-48-12D-4	REQUIRES 5 TOTAL PADS
TSSU-48-12D-4-LP	REQUIRES 5 TOTAL PADS
TSSU-48-12-LP	REQUIRES 5 TOTAL PADS
TSSU-48-12M	REQUIRES 5 TOTAL PADS
TSSU-48-12M-B	REQUIRES 5 TOTAL PADS
TSSU-48-12MB-LP	REQUIRES 5 TOTAL PADS
TSSU-48-15M	REQUIRES 5 TOTAL PADS
TSSU-48-15M-B	REQUIRES 5 TOTAL PADS
TSSU-48-15MB-LP	REQUIRES 5 TOTAL PADS
TSSU-48-18M	REQUIRES 5 TOTAL PADS
TSSU-48-18M-B	REQUIRES 5 TOTAL PADS
TSSU-48-18MB-D4	REQUIRES 5 TOTAL PADS
TSSU-48-18MB-LP	REQUIRES 5 TOTAL PADS
TSSU-48-8-LP	REQUIRES 5 TOTAL PADS
TSSU-48-8M	REQUIRES 5 TOTAL PADS
TSSU-60-08	REQUIRES 5 TOTAL PADS
TSSU-60-08-LP	REQUIRES 5 TOTAL PADS
TSSU-60-10	REQUIRES 5 TOTAL PADS
TSSU-60-10-LP	REQUIRES 5 TOTAL PADS
TSSU-60-12	REQUIRES 5 TOTAL PADS
TSSU-60-12-LP	REQUIRES 5 TOTAL PADS

TSSU-60-12M-B	REQUIRES 5 TOTAL PADS
TSSU-60-14	REQUIRES 5 TOTAL PADS
TSSU-60-15M-B	REQUIRES 5 TOTAL PADS
TSSU-60-16	REQUIRES 5 TOTAL PADS
TSSU-60-16D-2	REQUIRES 5 TOTAL PADS
TSSU-60-16D-4	REQUIRES 5 TOTAL PADS
TSSU-60-16D-4-LP	REQUIRES 5 TOTAL PADS
TSSU-60-16-DS	REQUIRES 5 TOTAL PADS
TSSU-60-16-DS-LP	REQUIRES 5 TOTAL PADS
TSSU-60-16-DS-ST	REQUIRES 5 TOTAL PADS
TSSU-60-16-LP	REQUIRES 5 TOTAL PADS
TSSU-60-16-ST	REQUIRES 5 TOTAL PADS
TSSU-60-18M-B	REQUIRES 5 TOTAL PADS
TSSU-60-21M	REQUIRES 5 TOTAL PADS
TSSU-60-24M	REQUIRES 5 TOTAL PADS
TSSU-60-24M-B	REQUIRES 5 TOTAL PADS
TSSU-60-24MB-DS	REQUIRES 5 TOTAL PADS
TSSU-60-24MB-DS-LP	REQUIRES 5 TOTAL PADS
TSSU-60-24M-B-DS-ST	REQUIRES 5 TOTAL PADS
TSSU-60-24MB-LP	REQUIRES 5 TOTAL PADS
TSSU-60-24M-B-ST	REQUIRES 5 TOTAL PADS
TSSU-60-24M-DS	REQUIRES 5 TOTAL PADS
TSSU-72-08	REQUIRES 5 TOTAL PADS
TSSU-72-10	REQUIRES 5 TOTAL PADS
TSSU-72-12	REQUIRES 5 TOTAL PADS
TSSU-72-12D-4	REQUIRES 5 TOTAL PADS
TSSU-72-12M-B	REQUIRES 5 TOTAL PADS
TSSU-72-15M-B	REQUIRES 5 TOTAL PADS
TSSU-72-16	REQUIRES 5 TOTAL PADS
TSSU-72-18	REQUIRES 5 TOTAL PADS
TSSU-72-18D-2	REQUIRES 5 TOTAL PADS
TSSU-72-18D-4	REQUIRES 5 TOTAL PADS
TSSU-72-18M-B	REQUIRES 5 TOTAL PADS
TSSU-72-18-ST	REQUIRES 5 TOTAL PADS

TSSU-72-24M-B-ST	REQUIRES 5 TOTAL PADS
TSSU-72-30M	REQUIRES 5 TOTAL PADS
TSSU-72-30MB	REQUIRES 5 TOTAL PADS
TSSU-72-30MB-DS	REQUIRES 5 TOTAL PADS
TSSU-72-30M-B-DS-ST	REQUIRES 5 TOTAL PADS
TSSU-72-30M-B-ST	REQUIRES 5 TOTAL PADS
TSSU-72-30MB-ST-D2	REQUIRES 5 TOTAL PADS
TUC-119	REQUIRES 5 TOTAL PADS
TUC-119D-2	REQUIRES 5 TOTAL PADS
TUC-119D-4	REQUIRES 5 TOTAL PADS
TUC-119D-6	REQUIRES 5 TOTAL PADS
TUC-119D-8	REQUIRES 5 TOTAL PADS
TUC-27	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TUC-27D-2	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TUC-27D-2-LP	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TUC-27F	REQUIRES 5 TOTAL PADS
TUC-27F-D-2	REQUIRES 5 TOTAL PADS
TUC-27FG	REQUIRES 5 TOTAL PADS
TUC-27G	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TUC-27G-LP	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TUC-27-LP	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TUC-36	REQUIRES 5 TOTAL PADS
TUC-36F	REQUIRES 5 TOTAL PADS
TUC-44	REQUIRES 5 TOTAL PADS
TUC-44D-2	REQUIRES 5 TOTAL PADS
TUC-44F	REQUIRES 5 TOTAL PADS
TUC-44F-HD	REQUIRES 5 TOTAL PADS
TUC-44HD	REQUIRES 5 TOTAL PADS
TUC-48	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-48D-2	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-48D-2-LP	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-48D-4	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-48D-4-LP	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-48F	USED BEFORE 10/20/15 PER PCN 8251. REQUIRES 5 TOTAL PADS

TUC-48F-D	USED BEFORE 10/20/15 PER PCN 8251. REQUIRES 5 TOTAL PADS
TUC-48F-D-4	USED BEFORE 10/20/15 PER PCN 8251. REQUIRES 5 TOTAL PADS
TUC-48F-LP	USED BEFORE 10/20/15 PER PCN 8251. REQUIRES 5 TOTAL PADS
TUC-48G	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-48G-LP	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-48-LP	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TUC-60	REQUIRES 5 TOTAL PADS
TUC-60-32	REQUIRES 5 TOTAL PADS
TUC-60-32D-2	REQUIRES 5 TOTAL PADS
TUC-60-32F	REQUIRES 5 TOTAL PADS
TUC-60-32F-HD	REQUIRES 5 TOTAL PADS
TUC-60-32HD	REQUIRES 5 TOTAL PADS
TUC-60D-2	REQUIRES 5 TOTAL PADS
TUC-60D-2-LP	REQUIRES 5 TOTAL PADS
TUC-60D-4	REQUIRES 5 TOTAL PADS
TUC-60D-4-LP	REQUIRES 5 TOTAL PADS
TUC-60F	REQUIRES 5 TOTAL PADS
TUC-60F-LP	REQUIRES 5 TOTAL PADS
TUC-60G	REQUIRES 5 TOTAL PADS
TUC-60G-LP	REQUIRES 5 TOTAL PADS
TUC-60-LP	REQUIRES 5 TOTAL PADS
TUC-67	REQUIRES 5 TOTAL PADS
TUC-67D-2	REQUIRES 5 TOTAL PADS
TUC-67D-4	REQUIRES 5 TOTAL PADS
TUC-67F	REQUIRES 5 TOTAL PADS
TUC-67F-HD	REQUIRES 5 TOTAL PADS
TUC-67HD	REQUIRES 5 TOTAL PADS
TUC-72	REQUIRES 5 TOTAL PADS
TUC-72F	REQUIRES 5 TOTAL PADS
TUC-93	REQUIRES 5 TOTAL PADS
TUC-93D-2	REQUIRES 5 TOTAL PADS
TUC-93D-4	REQUIRES 5 TOTAL PADS
TUC-93D-6	REQUIRES 5 TOTAL PADS
TUC-93F	REQUIRES 5 TOTAL PADS

TUC-93F-HD	REQUIRES 5 TOTAL PADS
TUC-93HD	REQUIRES 5 TOTAL PADS
TUC-GAL-48	REQUIRES 5 TOTAL PADS
TUC-GAL-48-2	REQUIRES 5 TOTAL PADS
TUC-GAL-48F	REQUIRES 5 TOTAL PADS
TUC-GAL-93	REQUIRES 5 TOTAL PADS
TVM-400	REQUIRES 5 TOTAL PADS
TWT-119	REQUIRES 5 TOTAL PADS
TWT-119D-2	REQUIRES 5 TOTAL PADS
TWT-119D-4	REQUIRES 5 TOTAL PADS
TWT-119D-6	REQUIRES 5 TOTAL PADS
TWT-119D-8	REQUIRES 5 TOTAL PADS
TWT-27	REQUIRES 5 TOTAL PADS
TWT-27D-2	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TWT-27D-2-LP	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TWT-27F	REQUIRES 5 TOTAL PADS
TWT-27F-D2	REQUIRES 5 TOTAL PADS
TWT-27FG	REQUIRES 5 TOTAL PADS
TWT-27G	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TWT-27LP	USED BEFORE 11/2/14 PER PCN 7881. REQUIRES 5 TOTAL PADS
TWT-36	REQUIRES 5 TOTAL PADS
TWT-36F	REQUIRES 5 TOTAL PADS
TWT-36LP	REQUIRES 5 TOTAL PADS
TWT-44	REQUIRES 5 TOTAL PADS
TWT-44D-2	REQUIRES 5 TOTAL PADS
TWT-44F	REQUIRES 5 TOTAL PADS
TWT-44F-HD	REQUIRES 5 TOTAL PADS
TWT-44HD	REQUIRES 5 TOTAL PADS
TWT-48	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TWT-48D-2	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TWT-48D-4	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TWT-48D-4-LP	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TWT-48F	USED BEFORE 10/20/15 PER PCN 8251. REQUIRES 5 TOTAL PADS
TWT-48F-D4	USED BEFORE 10/20/15 PER PCN 8251. REQUIRES 5 TOTAL PADS

TWT-48G	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TWT-48-LP	USED BEFORE 10/20/15 PER PCN 8119. REQUIRES 5 TOTAL PADS
TWT-60	REQUIRES 5 TOTAL PADS
TWT-60-32	REQUIRES 5 TOTAL PADS
TWT-60-32D-2	REQUIRES 5 TOTAL PADS
TWT-60-32F	REQUIRES 5 TOTAL PADS
TWT-60-32F-HD	REQUIRES 5 TOTAL PADS
TWT-60-32HD	REQUIRES 5 TOTAL PADS
TWT-60D-2	REQUIRES 5 TOTAL PADS
TWT-60D-2-LP	REQUIRES 5 TOTAL PADS
TWT-60D-4	REQUIRES 5 TOTAL PADS
TWT-60D-4-LP	REQUIRES 5 TOTAL PADS
TWT-60F	REQUIRES 5 TOTAL PADS
TWT-60G	REQUIRES 5 TOTAL PADS
TWT-67	REQUIRES 5 TOTAL PADS
TWT-67D-2	REQUIRES 5 TOTAL PADS
TWT-67D-4	REQUIRES 5 TOTAL PADS
TWT-67F	REQUIRES 5 TOTAL PADS
TWT-67F-HD	REQUIRES 5 TOTAL PADS
TWT-67HD	REQUIRES 5 TOTAL PADS
TWT-72	REQUIRES 5 TOTAL PADS
TWT-72F	REQUIRES 5 TOTAL PADS
TWT-93	REQUIRES 5 TOTAL PADS
TWT-93D-2	REQUIRES 5 TOTAL PADS
TWT-93D-4	REQUIRES 5 TOTAL PADS
TWT-93D-6	REQUIRES 5 TOTAL PADS
TWT-93F	REQUIRES 5 TOTAL PADS
TWT-93F-HD	REQUIRES 5 TOTAL PADS
TWT-93HD	REQUIRES 5 TOTAL PADS