

872401 Compatibility Notes - 06/11/2018

Model	Notes
TMG-65-18	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-95-38	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-48-18	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-36-12-S	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TMG-95-28	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TDG-50-18	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-36-12	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TDG-95-38	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-50-18	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TM-95-28	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TDG-65-24	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-24-07	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.

TM-65-18	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-50-18-S	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TDG-48-18	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-95-38-S	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-65-24-S	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-65-24	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TDG-36-12	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TDG-95-38-S	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.
TD-80-30	To tell the difference right versus left: Facing cabinet, hold plastic rail with 3/4" notched end toward you, grooved 2" side up toward ceiling and lip of slide toward center. This is the right rail.