

# Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (833) 665-6300 or email support@polywoodoutdoor.com

.....

•••••

.....



#### Share your space

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook! #polywood





#### Watch & Learn

For assembly videos and more, visit **youtube.com/polywood** 


# POLYWOOD

# Assembly Instructions





CTF42S



CTF42N, CTF42S, CTF48R

**Fire Pit Table** 



# 20-Year Warranty

To view our full warranty, please visit polywoodoutdoor.com/warranty

Easily register your product using one of the methods below:

#### Text POLYWOOD to 71403

Receive a link to register online


— or —

#### Register on our website register.polywoodoutdoor.com

— or —

#### **Send a Picture** Take a photo of the icon below and

text it to 71403 (US only)





### Cleaning Tips

Even POLYWOOD gets dirty – here are some ways to help keep it clean:


For a quick clean: Simply wipe down with soap and water.

#### For a deeper clean:

You'll need:

- »  $^{1\!\!/_3}$  bleach and  $^{2\!\!/_3}$  water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.



Something missing? Call (833) 665-6300

