

How to remove and replace the lid

(for CW1385, CW1386, CW1387)

Step 1: To remove the lid, you will manually lift the lid by the trim



Step 2: Then pinch the two plastic tabs together to release, then lift upward to remove



Step 3: Take the new lid and pinch the two plastic tabs together, ensure the hinges are aligned then release the tabs



Step 4: Tilt and adjust the lid assembly forward to ensure the tabs are locked into position and the step is complete

