Hoshizaki America, Inc.

Ice Bin

Models B-1150SS B-1300SS B-1500SS B-1650SS

PARTS LIST



"A Superior Degree of Reliability"

www.hoshizaki.com



Number: 71238 Issued: 3-9-2005 Revised: 1-21-2015

CONTENTS

Auxiliary Codes	. 3
Note About Ordering Parts	. 3
A. Bin Assembly	
B. Snout Assembly	. 5
C. Door Assembly	. 6
D. Accessories & Options	. 7

Auxiliary Codes

B-1150SS

DIIU		D-130	000
Q-5	August 2005	Q-5	August 2005
R-5	December 2005	R-5	December 2005
R-6	September 2006	R-6	September 2006
S-5	January 2007	S-5	January 2007
T-5	January 2008	T-5	January 2008
U-5	January 2009	U-5	January 2009
V-5	January 2010	V-5	January 2010
A-5	January 2011	A-5	January 2011
B-5	January 2012	B-5	January 2012
C-5	January 2013	C-5	January 2013
D-5	January 2014	D-5	January 2014
E-5	January 2015	E-5	January 2015
D 400	200		
B-130	055	B-165	OSS
B-130 P-5		B-165 P-5	
	August 2004 March 2005	P-5	August 2004
P-5 Q-5	August 2004	P-5 Q-5	August 2004 March 2005
P-5	August 2004 March 2005 December 2005	P-5 Q-5 R-5	August 2004 March 2005 December 2005
P-5 Q-5 R-5	August 2004 March 2005 December 2005 September 2006	P-5 Q-5	August 2004 March 2005 December 2005 September 2006
P-5 Q-5 R-5 R-6	August 2004 March 2005 December 2005 September 2006 January 2007	P-5 Q-5 R-5 R-6	August 2004 March 2005 December 2005 September 2006 January 2007
P-5 Q-5 R-5 R-6 S-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008	P-5 Q-5 R-5 R-6 S-5 T-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008
P-5 Q-5 R-5 R-6 S-5 T-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 January 2009	P-5 Q-5 R-5 R-6 S-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 February 2009
P-5 Q-5 R-5 R-6 S-5 T-5 U-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008	P-5 Q-5 R-5 R-6 S-5 T-5 U-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 February 2009 January 2010
P-5 Q-5 R-5 R-6 S-5 T-5 U-5 V-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 January 2009 January 2010	P-5 Q-5 R-5 R-6 S-5 T-5 U-5 V-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 February 2009 January 2010 January 2011
P-5 Q-5 R-5 S-5 T-5 U-5 V-5 A-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 January 2009 January 2010 January 2011	P-5 Q-5 R-5 S-5 T-5 U-5 V-5 A-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 February 2009 January 2010 January 2011 January 2012
P-5 Q-5 R-6 S-5 T-5 U-5 V-5 A-5 B-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 January 2009 January 2010 January 2011 January 2012	P-5 Q-5 R-6 S-5 T-5 U-5 V-5 A-5 B-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 February 2009 January 2010 January 2011
P-5 Q-5 R-5 S-5 T-5 U-5 V-5 A-5 B-5 C-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 January 2009 January 2010 January 2011 January 2012 January 2013	P-5 Q-5 R-5 S-5 T-5 U-5 V-5 A-5 B-5 C-5	August 2004 March 2005 December 2005 September 2006 January 2007 January 2008 February 2009 January 2010 January 2011 January 2012 January 2013

B-1500SS

Auxiliary Code Breakdown

The auxiliary code is the first two characters in the serial number. The first character indicates the year. Years progress or regress in alphabetical order. The series runs from "A" through "V" and the letters "I" and "O" are skipped. The second character indicates significant part changes within a year. Base is "5" and this number advances for each change. In cases where there is a letter in parentheses, this designates the month. This is the last character in the serial number. The series runs from "(A)" through "(M)" and the letter "(I)" is skipped. This designation is only included when identifying a parts change within an auxiliary code.

Note About Ordering Parts

Most assemblies cannot be ordered as complete units; parts in the assemblies generally must be ordered separately.

A. Bin Assembly B-1150SS, B-1300SS, B-1500SS, B-1650SS

P-5 to E-5



Title: A	Title: A. Bin Assembly Model: B-1150SS, B-1300SS, B-1500SS, B-1650SS											
				Required Number								
Index No.	Description	Material or Model Number	Port Number	P-5 to Q-5	R-5 to E-5							
1	Description Bin	B-1150SS	2A3602G01	4-5	⊃ 1							
I		B-1300SS	2A3062G01 2A3064G01	1	1							
		B-1500SS	2A3621G01	1	1							
		B-1650SS	2A3088G01	1	1							
2	Top Kit	B-1150SS	2A3424G01	1	1							
		B-1300SS	2A3070G01	1	-							
			2A3424G01		1							
		B-1500SS B-1650SS	2A3248G01	1	1							
3	Sliding Door		2A3079-01	2	2							
4	Drain Cap		322015-01	1	1							

B. Snout Assembly

B-1150SS, B-1300SS, B-1500SS, B-1650SS P-5 to E-5



Title: B. Snout Assembly Model: B-1150SS, B-1300SS, B-1500SS, B-1650SS												
				Required Number								
							S-5	U-5				
				P-5			to	(K)				
Index		Material or		to		_	U-5	to				
No.	Description	Model Number	Part Number	Q-5	R-5	R-6	(J)	E-5				
1	Left Snout		1A0923-01	1	1	-						
			1A1287-01			1	1	1				
2	Right Snout		1A0930-01	1	1	-						
			1A1286-01			1	1	1				
3	Truss Head Screw	6×20 SS	4A3454-02	14	14	14	14	14				
4	Snout Bottom (A)		1A0925-01	1	1	1	1	1				
5	Snout Bottom (B)		1A0931-01	1	1	1	1	1				
6	Snout Top Assembly		2A3069G01	1	-					1		
			2A3585G01		1	-						
			2A4024G01			1	-					
			2A4024G02				1	1				
7	Round Vinyl Cap		4A3498-01	8	8	8	8	8				
8	Baffle		2A3073-01	1	1	-						
			2A4030-01			1	1	-				
			2A5390-01					1				
9	Left Side Cover		3A3080-01	1	1	1	1	1				
10	Right Side Cover		3A3091-01	1	1	1	1	1				

C. Door Assembly

B-1150SS, B-1300SS, B-1500SS, B-1650SS P-5 to E-5



Title: C	Title: C. Door Assembly Model: Model: B-1150SS, B-1300SS, B-1500SS, B-1650SS										
				Required Number							
				P-5							
Index		Material or		to							
No.	Description	Model Number	Part Number	E-5							
1	Door		1A0926G01	1							
2	Door Gasket	5×12 SS	3A3330-01	1							
3	Hinge Support		4A3803-01	2							
3a	Countersunk Screw	5×12 SS	4A2894-01	4							
4	Hinge		4A3360-01	2							
4a	Truss Head Screw	M6 SS	4A3360F02	2							
4b	Tooth Washer	M4	4A3360F03	2							
4c	Washer		4A3361-01	2							
5	Left Hinge Bracket		3A3089-01	1							
6	Right Hinge Bracket		3A3090-01	1							

D. Accessories & Options B-1150SS, B-1300SS, B-1500SS, B-1650SS P-5 to E-5



Title: D	D. Accessories & Options Mo	del: B-1150SS, I	B-1300SS, B-1	500S	S, B-1	650SS	;				
							Requ	ired N	lumbei	r	
				P-5	R-5						
Index		Material or		to	to						
No.	Description	Model Number	Part Number	Q-5	E-5						
			Accessories								
1	Leg-Box Of 4		4A0390-01	1	1						
2	Scoop		4A2246-01	1	1						
3	Snout Gasket		4A3474-01	1	1						
			Options								
4	Top Kit Cover		3A3197G01	1	-						
		HS-2111	4A3908A01		1						
5	Probe	HS-2108	4A3742A01	1	1						
6	Shovel	HS-2107	4A3741A01	1	1						
7	Scoop Holder Kit	HS-2106	4A3740A01	1	1				1		