

# Melamine Econoline Top

## USE & CARE INSTRUCTIONS

A Melamine work surface will give you years of service if used with the same care you would give to a real wood furniture top.

1. Clean surface with a damp cloth, and then dry. Use a couple of drops of dish-washing detergent for stubborn stains. Be sure to dry the top after cleaning.
2. Crayons marks may be removed by using a cloth dampened with a few drops of mineral spirits (paint thinner, Goo Gone, Good Off), or similar solvent. Then wipe the surface dry.
3. Permanent marker can be removed by using a cloth dampened with a few drops of fingernail polish remover, or lacquer thinner. Then wipe the surface dry.
4. Do not leave wet objects on the top for long periods of time. Wipe up spills at once.
5. Do not place hot objects directly on the table top.
6. Use care to prevent scratching the top. Melamine is scratch resistant, it is not scratch proof. Treat the top with the same care you would give to the wood furniture in your home or office, and it will give you years of service.

### WARRANTY

This table has a 1-Year Warranty against Defects in Materials and/or Workmanship. This Warranty does not cover normal wear, abuse, accidental damage, improper assembly or failure to follow the Use & Care Instructions.