



FLAVOUR BLASTER

AROMA GUN KIT INCLUDES



AROMA GUN PRO 2.6

USB-C MAGNETIC CABLE

DISPOSABLE TANK


X4 CITRUS AROMA

BUBBLE X SOLUTION

ATOMISER

BUBBLE X BOWL

QUICK START



1
CHARGE BLASTER
Insert USB-C Cable




2
FILL TANK
Pour Aroma into the Tank



3
INSERT TANK & ADD NOZZLE
Connect to Mag Base



4
TURN ON
Press trigger 3x. Repeat to turn off.



5
DIP NOZZLE TIP
Gently shake BubbleX pour into bowl and dip nozzle tip



6
HOLD TRIGGER
Create Aroma filled bubbles.

LED INDICATOR

To charge your flavour blaster battery connect the correctly powered USB-C magnetic cable to the USB-C input port. The screen will show the battery charge percentage. A full battery charge will take 8 hours, giving the flavour blaster 8 hours of usage time.



1. 100% BATTERY




2. 80% BATTERY



3. 60% BATTERY



4. 40% BATTERY



5. 10% (FLASHING)



**6. NO BATTERY
(PLUG IN USB-C)**

1. WHITE LED FLASHES

- x3 Temperature too high
- x4 Excess use heat protection
- x5 Power On/Off

2. RED LED FLASHES

- x3 Tank not detected
- x5 Battery wattage low

3. GREEN LED FLASHES

- x3 Coil needs replacing
- x5 Tank detected

AROMA TANK



1

OPEN THE TANK

Slide the lid open to reveal the fill port.



2

FILL WITH AROMA

Pour aroma into the tank, leaving a gap at the top. Slide the lid and use the designated section, not the central hole.



3

CLOSE THE TANK

Slide the lid fully shut so it's snug and secure.



4

INSTALL

Insert the tank into your Flavour Blaster device until seated firmly.

HOW TO VIDEO




SCAN ME

SWITCHING AROMAS FAST!

Because the tank has a built in coil, switching is quick, with minimal cross aroma carryover and no priming required.

1. Remove the current tank from the device (if fitted) and close the lid. Store upright.
2. Slide open a fresh tank, fill with the new aroma, and close.
3. Insert the new tank and continue service — no training or coil changes required.



BEST PRACTICE



CLEAR BUBBLES

Press trigger twice before dipping nozzle tip into Bubble X to blow clear bubbles. To return to smoke, press trigger twice.



ATOMISER

Twist and remove inner tube from Atomiser outer casing and fill with water. Increase bubble success rate by spraying drink/glassware 1-2 times with water.



MAINTENANCE

Remove Tank when not in use
Store Tank upright. Clean with alcohol wipe after use. Replace after 1,000 uses (4x 10ml Aroma Bottle).



BUBBLE SUCCESS

Bubbles work best on shaken cocktails served up with a high washline. Note that the Flavour Blaster can be used on all kinds of food and drink.



BATTERY



PLEASE READ AND ADHERE TO THE FOLLOWING WARNINGS WHEN CHARGING YOUR DEVICE:

Only charge the Aroma Gun with a high quality CE & UL Certified wall charger. Never charge a Battery that has been damaged or dropped. Never plug a Charger into a non-approved Mains Power Transformer. Do not overcharge, remove the USB-C Magnetic Cable from the Aroma Gun when complete to prolong battery life. Remove Tank before charging. Never leave a charging battery unattended. Only use the included high quality USB-C Magnetic Charging Cable. Do not charge your Aroma Gun in your car. Remove the Tank from the Aroma Gun when shipping or travelling. If there are any issues with the device please contact Flavour Blaster immediately.

FURTHER INFORMATION



@FlavourBlaster



@theflavourblaster



VIDEO TUTORIAL



FLAVOUR BLASTER PROVIDES A 12 MONTH GUARANTEE
FOR HELP AND INFORMATION PLEASE CONTACT [INFO@FLAVOURBLASTER.COM](mailto:info@flavourblaster.com)

WWW.FLAVOURBLASTER.COM