

FLAVOUR BLASTER

# **AROMA GUN KIT INCLUDES**



### **AROMA GUN MINI 2**

**USB-C MAGNETIC CABLE** 

**DISPOSABLE TANK** 

X2 PASSIONFRUIT AROMA

**BUBBLE X SOLUTION** 

**ATOMISER** 

**BUBBLE X BOWL** 

## MINI DISPLAY

SAFETY
Allow tank to
cool down for
5 seconds
before
continuing.

### PLEASE CHARGE BLASTER BEFORE USE







Flash 5 times Power on/off

Flash 5 times Tank detected

Flash 3 times
Tank temperature too high

### **RED LIGHT INDICATOR**



Flash 3 Times
Tank not detected





Flash 3 Times Overuse



### **Solid Light**

If Aroma Gun is out of charge, plug charger in to see lights flash. After 30 seconds all lights will go off. After approx. 30 minutes, press trigger to see lights begin to flash again. Leave until fully charged.

A full battery charge will take 6 hours, giving the Aroma Gun approx 6 hours of continuous usage time.

### **BATTERY POWER**



100% Power



70% Power



40% Power



10% Power



Less than 10% Power

# **QUICK START**



CHARGE BLASTER
Insert USB-C Cable



FILL TANK
Pour Aroma into the Tank



INSERT TANK & ADD NOZZLE
Connect to Mag Base



TURN ON
Press trigger 3x. Repeat to turn off.



**DIP NOZZLE TIP**Gently shake BubbleX pour into bowl and dip nozzle tip



**HOLD TRIGGER**Create Aroma filled bubbles.

## **BEST PRACTICE**



# DISPOSABLE TANK Slide the lid and pour aroma into the hole. Fill to the top of the logo and rest for 2 minutes.





#### **ATOMISER**

Twist and remove inner tube from Atomiser outer casing and fill with water. Increase bubble success rate by spraying drink/glassware 1-2 times with water.





#### **MAINTENANCE**

Remove Tank when not in use Store Tank upright. Clean with alcohol wipe after use. Replace after 1,000 uses (4x 10ml Aroma Bottle).





### **BUBBLE SUCCESS**

Bubbles work best on shaken cocktails served up with a high washline. Note that the Flavour Blaster can be used on all kinds of food and drink.



# **FURTHER INFORMATION**

