

## Restarting Hoshizaki REFRIGERATION after prolonged downtime

The following is a brief guide. For complete instructions and safety information, refer to the appliance's instruction manual. Manuals can be found at www.hoshizakiamerica.com/support. The appliance's model name can be found on the nameplate inside the cabinet.

SHUT DOWN Before shutting down the appliance for an extended period, follow the instructions below.

Before shutting down the appliance, remove all food products

Unplug the appliance

Clean the appliance as outlined in the Cleaning and Maintenance Instructions section of the appliance's instruction manual

Prevent the doors/drawers from closing to reduce the risk of children getting trapped and to help inhibit odors from forming

RESTART



Plug the appliance in to the electrical outlet. At startup, there is a slight delay before the compressor starts.

Allow the appliance to cool down prior to loading it with food products.

Note for Upright Models: If the cabinet temperature is not displayed on the control module, press and hold the standby button\* on the control module until "ON" appears in the display. Factory default is "ON."

\*For Commercial Series models: 1) Plug the appliance into the electrical outlet. 2) Move the power switch to the "ON" position to start the cool-down process.

Note for Prep Table Models: Wash the pans and cutting board before use. The entire rail must be covered by rail dividers and pans (up to 6" (15 cm) deep) and the rail cover must be closed. Otherwise, the appliance will not cool properly. Leave the pans empty until the appliance cools down.



Product manual ook up

Visit hoshizakiamerica.com for more information