

### BEFORE YOU BEGIN

Be sure to read all the instructions before attempting to assemble the Chalkboard Sign with Display Kit.

- Carefully remove all parts from the carton and inspect each part. If a part appears to be damaged or missing, please contact Rosseto Customer Support.

### PARTS & ACCESSORIES


- 1 Arch Beam
- 2 Arch Beam Supports
- 1 Chalkboard Sign
- 2 Chalkboard Sign Hanger Clips
- 2 M8x16mm Flat Head Thumbscrews

### CARE & CLEANING

- DO NOT put any part of the unit through dishwasher or dryer machine.
- ALWAYS use a non-abrasive sponge.
- DO NOT use any abrasive materials such as scrapers or metal-based brushes.
- DO NOT use harsh chemicals or abrasive cleaners.

### SPECIFICATIONS

Catalog Number	Assembled Dimensions	Assembled Weight
MT-BKDFK Chalkboard Sign w/Black Display Frame Kit	58.5 x 9.9 x 56.7 in. 148.6 x 25.1 x 144.1 cm	16.8 lbs/7.6 kg
MT-SSDFK Chalkboard Sign w/Stainless Steel Display Frame Kit	58.5 x 9.9 x 56.7 in. 148.6 x 25.1 x 144.1 cm	16.8 lbs/7.6 kg



1. Insert the rails on each arch beam support into table snaps under the table top on each side as shown below.
2. Insert the arch beam into the top holes in the arch beam supports.
3. Insert and hand tighten the thumbscrews as shown at right.
4. Install chalkboard hanger clips on the arch beam and hang the chalkboard sign.

