

Lavex Automatic Soap Dispenser Troubleshooting Guide

Issue: Soap dispenser not dispensing, and the light is not flashing red.

Solution: Ensure that the internal pump is fully seated in the dispenser. Refer to the images below for examples of correct and incorrect seating.

Correct Seating



Incorrect Seating

